

## INSPECTION

### 1. Bank 1, 2 Sensor 1:

#### INSPECT HEATER RESISTANCE OF HEATED OXYGEN SENSOR


- Disconnect the oxygen sensor connector.
- Using an ohmmeter, measure the resistance between terminals +B and HT.

**Resistance: 11 – 16  $\Omega$  at 20°C (68°F)**

If the resistance is not as specified, replace the sensor.

**Torque: 44 N·m (450 kgf·cm, 32 ft·lbf)**

- Reconnect the oxygen sensor connector.



### 2. Bank 1, 2 Sensor 2:

#### INSPECT HEATER RESISTANCE OF HEATED OXYGEN SENSOR

- Take out the floor carpet.
- Disconnect the oxygen sensor connector.
- Using an ohmmeter, measure the resistance between terminals +B and HT.

**Resistance: 11 – 16  $\Omega$  at 20°C (68°F)**

If the resistance is not as specified, replace the sensor.

**Torque: 44 N·m (450 kgf·cm, 32 ft·lbf)**

- Reconnect the oxygen sensor connector.
- Install the floor carpet.

### 3. INSPECT OPERATION OF HEATED OXYGEN SENSOR [\[See page DI-118\]](#)