

SERVICE HINTS

REAR FOG LIGHT RELAY

5-3 : Closed with rear fog light SW on, light control SW at **TAIL** or **HEAD** position

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
B6	A	72 (LHD)	J15	74 (LHD)	R6	74 (LHD)
J8		74 (LHD)	J18	74 (LHD)	R9	78 (LHD)
J10		74 (LHD)	J21	78 (LHD)	R11	78 (LHD)
J14		74 (LHD)	R5	74 (LHD)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
1G	59 (LHD)	
2F	60 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC3	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
IF	98 (LHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel
BK	102 (LHD)	Quarter Panel LH

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	102 (LHD)	Floor No.2 Wire	B6	102 (LHD)	Floor No.2 Wire

REAR FOG LIGHT (LHD EUROPE)

