

PROBLEM SYMPTOMS TABLE

• DOOR LOCK CONTROL

| Symptom | Suspect Area | See page |
|---|---|---|
| Lock or unlock cannot be operated with door lock control S/W. | 1. Door lock control switch circuit (D or P) 2. Driver Door ECU (or Passenger Door ECU) 3. Body No.1 ECU | DI-710 DI-742 IN-29 |
| Door key linked function does not operate. | 1. Door key lock and unlock switch circuit (D or P) 2. Driver Door ECU (or Passenger Door ECU) 3. Body No.1 ECU | DI-716 DI-748 IN-29 |
| Key confinement prevention function does not operate. | 1. Key unlock switch circuit 2. Body No.2 ECU 3. Body No.1 ECU | DI-664 |
| Does not lock and unlock each door only. | 1. Door lock motor circuit 2. Any door ECU | DI-712 DI-744 DI-775 DI-793 IN-29 |
| Luggage compartment door opener function does not operate. | 1. Luggage compartment door opener switch circuit 2. Luggage compartment door opener motor circuit 3. Body No.1 ECU | DI-652 DI-638 |

• WIRELESS DOOR LOCK CONTROL

| Symptom | Suspect Area | See page |
|---|--|---|
| All function of wireless door lock control system do not operate. | 1. Transmitter 2. Wireless tuner circuit 3. Key unlock warning switch circuit 4. Body No.2 ECU 5. Body No.1 ECU | BE-171 DI-624 DI-664 |
| Lock (or unlock) function does not operate. | 1. Door key lock and unlock switch circuit 2. Door unlock detection switch circuit 3. Any door ECU 4. Body No.1 ECU | DI-716 DI-748 DI-714 DI-746 DI-777 DI-795 IN-29 |
| Automatic lock function operates even if any door is opened within 30 seconds after all doors are unlocked by wireless door lock control system . | 1. Door courtesy switch circuit 2. Any door ECU 3. Body No.1 ECU | DI-718 DI-750 DI-779 DI-797 IN-29 |
| Wireless door lock operates, but the buzzer does not sound. | 1. Wireless door lock buzzer circuit 2. Body No.1 ECU | DI-636 |
| Buzzer sound, but wireless door lock function does not operate. | 1. Body No.1 ECU | |
| Luggage compartment door opener. | 1. Luggage compartment door opener motor circuit 2. Body No.1 ECU | DI-638 |

• THEFT/DETERRENT SYSTEM

| Symptom | Suspect Area | See page |
|--|--|---|
| No alerting condition is operated. (The system cannot be set.) | 1. Theft/deterrent indicator circuit 2. Key/unlock/warning switch circuit 3. Courtesy switch circuit 4. Door/unlock/detection switch circuit 5. Engine/hood/courtesy switch circuit 6. Luggage room/door/courtesy switch circuit 7. Any door ECU 8. Body/No.2 ECU 9. Body/No.1 ECU | DI-644 DI-664 DI-718 DI-750 DI-779 DI-797 DI-714 DI-746 DI-777 DI-795 DI-626 DI-628 IN-29 |
| Cannot be canceled when IG is ON with a key. | 1. Key/unlock/warning switch circuit 2. Ignition switch circuit 3. Body/No.2 ECU 4. Body/No.1 ECU | DI-664 BE-31 |
| Cannot be canceled when unlocking the luggage compartment door with a key. | 1. Luggage room/courtesy switch circuit 2. Body/No.1 ECU | DI-628 |
| Some of the system does not operate. (Headlight does not light up.) | 1. Headlight relay circuit 2. Body/No.2 ECU 3. Body/No.1 ECU | DI-683 |
| Some of the system does not operate. (Taillight does not light up.) | 1. Taillight relay circuit 2. Body/No.2 ECU 3. Body/No.1 ECU | DI-681 |
| Some of the system does not operate. (Hazard does not light up.) | 1. Hazard switch circuit 2. Body/No.1 ECU | DI-650 |
| Theft/deterrent horn or horn does not sound | 1. Theft/deterrent horn circuit 2. Horn circuit 3. Body/No.1 ECU | DI-640 DI-642 |
| During warning condition, cannot be canceled by unlocking the door with a key. | 1. Door/key/lock and unlock switch circuit 2. Driver/Door ECU (or Passenger/Door ECU) 3. Body/No.1 ECU | DI-716 DI-748 IN-29 |
| During warning condition, cannot be canceled by unlocking the door with a key. (transmitter) | 1. Transmitter 2. Wireless tuner circuit 3. Body/No.1 ECU | BE-171 DI-624 |
| During warning condition, cannot be cancelled by turning the ACC or ON with a key. | 1. Ignition switch 2. Key/unlock/warning switch circuit 3. Body/No.2 ECU 4. Body/No.1 ECU | BE-31 DI-664 |
| The system operated for more 60 records. | 1. Body/No.1 ECU | |

• OTHERS

| Symptom | Suspect Area | See page |
|--|---|------------------------|
| Does not turn off the passenger seat belt warning light. | 1. Passenger buckle switch circuit 2. Body No.1 ECU | DI-621 |
| Rear window defogger does not operate. | 1. Defogger relay circuit 2. Defogger switch (A/C ECU) 3. Body No.1 ECU | DI-648 |
| Body No.1 ECU does not operate. | 1. Power source circuit 2. Body No.1 ECU | DI-619 |