

INSTALLATION

Installation is in the reverse order of removal (See page SA-36).

AFTER INSTALLATION, CHECK FRONT WHEEL ALIGNMENT (See page SA-4)