



## DISASSEMBLY

### REMOVE SUSPENSION SUPPORT AND COIL SPRING

(a) Using SST, compress the coil spring.

SST 09727-30021

#### NOTICE:

**Do not use an impact wrench. It will damage the SST.**

(b) Remove the suspension support nut.

(c) Remove these parts from the shock absorber:

- Washer
- 2 cushions
- Suspension support
- Upper insulator
- Collar
- Coil spring
- Lower cup
- Spring bumper