

DTC	B1272/72	Power seat ECU communication stop (w/Seat memory vehicle only)
------------	-----------------	-----------------------------------------------------------------------

CIRCUIT DESCRIPTION

This DTC is output when communication stops between power seat ECU and Body No. 1 ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1272/72	No communication from seat ECU more than 10 seconds.	<ul style="list-style-type: none"> Power seat ECU Wireharness

WIRING DIAGRAM

See page DI-747

INSPECTION PROCEDURE

1	Check power seat ECU.
----------	------------------------------

CHECK:

Check that the operation of front vertical and rear vertical is normal.

HINT:


With this inspection, the power seat ECU CPU can be diagnosed if it works normally or not.

NG

Replace the power seat ECU.

OK

2 Check wireharness



PREPARATION:

(): RHD models:

Disconnect connector "R13" (or "R14") of rear right door ECU, "P19" of power seat ECU and "R14" (or "R13") of rear left door ECU.

CHECK:

- Check continuity between terminals MPX2 of rear right (or left) door ECU and MPX1 of power seat ECU.
- Check continuity between terminals MPX2 of power seat ECU and MPX1 of rear left (or right) door ECU.

OK:

Continuity exists in wireharness of both (a) and (b), or either (a) or (b).

HINT:

If there is OPEN in wireharness of either (a) or (b), please repair it.

NG

Repair or replace wireharness.

OK

Replace power seat ECU.