

## PROBLEM SYMPTOMS TABLE

### • POWER WINDOW CONTROL SYSTEM

Symptom	Suspect Area	See page
Power window does not operate.	1. Power window switch circuit 2. Power window motor circuit 3. Passenger door ECU	<a href="#">DI-752</a> <a href="#">DI-754</a>
Auto up (or down) function does not operate.	1. Power window switch circuit 2. Passenger door ECU	<a href="#">DI-752</a>
Jam protection function and auto up (or down) function does not operate.	1. Jam protection limit switch circuit 2. Jam protection pulse switch circuit 2. Passenger door ECU	<a href="#">DI-756</a> <a href="#">DI-758</a>

### • POWER MIRROR CONTROL SYSTEM

Symptom	Suspect Area	See page
Both right and left mirror does not operate.	1. Mirror switch circuit 2. Body No.2 ECU	<a href="#">DI-673</a>
Only one side of mirror does not operate.	1. Mirror motor circuit 2. Passenger door ECU	<a href="#">DI-760</a>
Mirror on the opposite side will be operated.	1. Mirror switch circuit	<a href="#">DI-673</a>
Mirror will not be operated as indicated with switch.	2. Body No.2 ECU	

### • OTHERS

Symptom	Suspect Area	See page
Parts of the door does not function.	1. Power source circuit 2. Passenger door ECU	<a href="#">DI-739</a>