

## REMOVAL

REMOVE STEERING WHEEL AND SPIRAL CABLE (See page SR-12)