

## INSPECTION

1. **CHECK CONNECTIONS FOR LOOSENESS OR DAMAGE**
2. **CHECK CLAMPS FOR WEAKNESS, CRACKS OR DAMAGE**
3. **CHECK FOR DENTS OR DAMAGE**

If any part of the protector is damaged or dented to the extent that it contacts the three-way catalytic converter, repair or replace it.

4. **CHECK HEAT INSULATOR FOR DAMAGE**
5. **CHECK FOR ADEQUATE CLEARANCE BETWEEN CATALYTIC CONVERTER AND HEAT INSULATOR**