

<b>DTC</b>	<b>C1233 / 33, C1234 / 34</b>	<b>Yaw Rate Sensor Circuit</b>
------------	-------------------------------	--------------------------------


## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1233 / 33	When any of the following (1) through (4) is detected: (1) ECU terminal IG1 voltage is 9.5 V to 17.0 V, and the condition that yaw rate sensor voltage is out of the range from 0.25 V to 4.75 V continued for 1 sec. or more. (2) The conditions that yaw rate sensor open detect circuit signal is ON and the voltage of ECU terminal IG1 is 9.5 to 17 V continued for 1 sec. or more. (3) The conditions that yaw rate sensor power source voltage is out of the range from 4.4 V to 5.6 V and the voltage of ECU terminal IG1 is 9.5 to 17 V continued for 1 sec. or more. (4) When the condition that yaw rate sensor signal is momentarily open circuit occurs 10 times or more and the voltage of ECU terminal IG1 is 9.5 to 17 V.	<ul style="list-style-type: none"> <li>• Yaw rate sensor</li> <li>• Yaw rate sensor circuit</li> </ul>
C1234 / 34	Condition (1) or (2) is detected: (1) When the condition that yaw rate sensor VYS terminal voltage is 4.75 V to 5.25 V and YD malfunction signal of yaw rate sensor is ON continued for 5 secs. or more. (2) Shift lever position is in P range and output voltage of yaw rate sensor is out of the range from 2.4 V to 2.6 V or after the difference from zero point calibration voltage of yaw rate sensor has become 0.08 V or more and when the condition that the vehicle speed exceeds more than 15 km/h (9 mph) while output condition of yaw rate sensor has been repeated.	

Fail safe function:

If trouble occurs in the yaw rate sensor circuit, the ECU prohibits TRC & VSC controls.

WIRING DIAGRAM




INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 in case of using the hand-held tester and start from step 3 in case of not using the hand-held tester.

1	Check output value of the yaw rate sensor.
---	--



**PREPARATION:**

- (a) Remove the 2 bolts and yaw rate sensor with connector still connected.
- (b) Connect the hand-held tester to the DLC3.
- (c) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (d) Select the DATALIST mode on the hand-held tester.


**CHECK:**

Check that the yaw rate value of the yaw rate sensor displayed on the hand-held tester is changing : Place the yaw rate sensor vertically to the ground and turn the sensor pivoted on its center.

**OK:**

Yaw rate value must be changing.

OK	Go to step 4.
----	---------------




- 2** Check whether continuity exists between terminal YD of yaw rate sensor and terminal YD of ABS & TRC & VSC ECU.

**NO**

Repair or replace harness or connector.

**YES**

- 3** Check voltage between terminals YD and GND of ABS & TRC & VSC ECU.



**PREPARATION:**

Remove ABS & TRC & VSC ECU with connector still connected.

**CHECK:**

- (a) Turn the IG switch ON.
- (b) Measure voltage between terminals YD and GND of ABS & TRC & VSC ECU.

**OK:**

**Voltage: 4.5 – 5.3 V**


**NG**

Replace yaw rate sensor.

**OK**

Check and replace ABS & TRC & VSC ECU.

**4 Check yaw rate sensor.**



**CHECK:**

- (a) Turn the IG switch ON.
- (b) Measure voltage between terminals 1 and 3, 3 and 4 of the yaw rate sensor with connector still connected.

**OK:**

Terminals 1 and 3 (YAW - GYAW)	Approx. 2.5V
Terminals 3 and 4 (GYAW - YD)	Approx. 4.5V - 5.3V

**NG**

**Replace yaw rate sensor.**

**OK**

**5 Check for open and short circuit in harness and connector between yaw rate sensor and ABS & TRC & VSC ECU (See page N-29).**

**NG**

**Repair or replace harness or connector.**

**OK**

**Check and replace ABS & TRC & VSC ECU.**