

# ILLUMINATION (RHD)

## SERVICE HINTS

### TAIL RELAY

5-3 : Closed with light control SW at **TAIL** or **HEAD** position

### C13 (A), (B) LIGHT CONTROL SW [COMB. SW]

(A) 15-(A) 16, (B) 15-(B) 9 : Closed with light control SW at **TAIL** or **HEAD** position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A16	86 (RHD)	G1	86 (RHD)	M2	88 (RHD)
A21	86 (RHD)	G2	86 (RHD)	R2	88 (RHD)
A36	90 (RHD)	H20	86 (RHD)	R6	88 (RHD)
A37	90 (RHD)	H21	86 (RHD)	R7	88 (RHD)
B6	A 86 (RHD)	H22	86 (RHD)	R13	92 (RHD)
C9	86 (RHD)	J32	88 (RHD)	R14	92 (RHD)
C13	A 86 (RHD)	J37	88 (RHD)	S4	88 (RHD)
	B 86 (RHD)	J38	88 (RHD)	V4	88 (RHD)
E11	86 (RHD)	J42	88 (RHD)		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	58 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1C	58 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1E	58 (RHD)	Floor No.1 Wire and Driver Side J/B (Right Kick Panel)
1F	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
1G	59 (RHD)	
1H		
3A	62	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)
3C		
3E	63	
3F		
3G		
3H		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	108 (RHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)
BA1	112 (RHD)	Rear Door LH Wire and Floor No.2 Wire (Under the Center Pillar LH)
BB1	112 (RHD)	Rear Door RH Wire and Floor No.1 Wire (Under the Center Pillar RH)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IF	108 (RHD)	Left Kick Panel
IG	108 (RHD)	Behind the Combination Meter
IH	108 (RHD)	Instrument Panel Brace LH
II	108 (RHD)	Cowl Side Panel RH
BJ	112 (RHD)	Rear Floor Partition Panel LH
BL	112 (RHD)	Rear Floor Partition Panel RH



## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I2	110 (RHD)	Cowl Wire	I7	110 (RHD)	Cowl Wire

