

## SERVICE HINTS

### C10 CLOCK

- 4-GROUND : Always approx. **12** volts (Power for clock)
- 5-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position (Power for indication)
- 1-GROUND : Always continuity

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B6	72 (LHD)	C10	86 (RHD)	J37	88 (RHD)
	86 (RHD)	J18	74 (LHD)		
C10	72 (LHD)	J32	88 (RHD)		

### □ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	58 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	58 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
2H	61 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)
	61 (RHD)	Cowl Wire and Passenger Side J/B (Left Kick Panel)
3A	62	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)
3B		
3G	63	

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID3	108 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Blower Unit)
IJ2	100 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)

### ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IF	108 (RHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel

