

# TROUBLESHOOTING

## PROBLEM SYMPTOMS TABLE

BE1YU-01

### Power Mirror Control System:

This system uses the multiplex communication system, so check diagnosis system of the multiplex communication system before you proceed with troubleshooting.

Symptom	Suspect Area	See page
G.C.C. countries only: Mirror retract system does not operate	1. Retract switch 2. Electrical retract motor 3. Wire harness 4. Body ECU No. 1 5. Driver door ECU Passenger door ECU	<a href="#">BE-21</a> <a href="#">BE-21</a> – <a href="#">DI-600</a> <a href="#">DI-628</a> <a href="#">DI-662</a>

### Double Locking System (Europe):

This system uses the multiplex communication system, so check diagnosis system of the multiplex communication system before you proceed with troubleshooting.

Symptom	Suspect Area	See page
All the doors double lock system does not operate.	1. Body ECU No. 1 2. Each door ECU	<a href="#">DI-600</a> –
Only one side of mirror does not operate.	1. Double lock motor 2. Double lock switch 3. Each door ECU 4. Body ECU No. 1	<a href="#">BE-18</a> <a href="#">BE-18</a> – <a href="#">DI-600</a>