


## ECU Power Source circuit

### CIRCUIT DESCRIPTION

The ECU Power Source supplies power to the CPU and sensors, etc. Power is supplied to the ECU even when the Ignition switch is Lock position.


### WIRING DIAGRAM



I04682

### INSPECTION PROCEDURE

#### 1 Check voltage between terminals ECUB and ECUE of ECU connector



F03693

#### PREPARATION:

Remove ECU with connectors still connected.

#### CHECK:

Measure voltage between terminals ECUB and ECUE of ECU connector.

#### OK:


Voltage: 10 - 16 V

OK

Proceed to next circuit inspection shown on the Problem Symptom Table. (See page DI-359)

NG

## 2 Check continuity between terminal ECUE of ECU connector and body ground.



### CHECK:

Measure resistance between terminal ECUE of ECU connector and body ground.

### OK:

Resistance: 1 KΩ or less

NG

Repair or replace harness or connector.

OK

## 3 Check MPX-B fuse.

### PREPARATION:

Remove MPX-B fuse from engine room P/B.

### CHECK:

Check continuity of MPX-B fuse.

### OK:

Continuity

NG

Check for short in harness and all components connected to MPX-B fuse.

OK

Check for open in harness and connector between ECU and battery. (See page IN-29)