

## PROBLEM SYMPTOMS TABLE

If a normal code is displayed the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

### NOTICE:

When replacing ABS & TRC & VSC ECU, sensor or etc., turn the IG switch OFF.

Symptom	Suspect Area	See page
TRC does not operate.	Only when inspection circuits for each problem symptom are all normal and the problem is still occurring, replace the ABS & TRC & VSC ECU. 1. Check the DTC, reconfirming that the normal code is output. 2. IG power source circuit. 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit.	DI-307  DI-241 DI-351 DI-224
VSC does not operate.	Only when inspection circuits for each problem symptom are all normal and the problem is still occurring, replace the ABS & TRC & VSC ECU. 1. Check the DTC, reconfirming that the normal code is output. 2. IG power source circuit. 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit. 5. Deceleration sensor circuit. 6. Yaw rate sensor circuit. 7. Steering angle sensor circuit.	DI-307  DI-241 DI-351 DI-224 DI-332 DI-334 DI-328
VSC warning light abnormal.	Only when inspection circuits for each problem symptom are all normal and the problem is still occurring, replace the ABS & TRC & VSC ECU. 1. VSC warning light circuit. 2. ABS & TRC & VSC ECU.	DI-342 IN-29
SLIP indicator light abnormal.	SLIP indicator light circuit.	DI-347
VSC OFF indicator abnormal.	Only when inspection circuits for each problem symptom are all normal and the problem is still occurring, replace the ABS & TRC & VSC ECU. 1. VSC OFF indicator light circuit. 2. VSC OFF switch circuit.	DI-344 DI-344
DTC check cannot be done.	Only when inspection circuits for each problem symptom are all normal and the problem is still occurring, replace the ABS & TRC & VSC ECU. 1. VSC warning light circuit. 2. Tc terminal circuit.	DI-342 DI-301