


REASSEMBLY

HINT:


Before reassembly, apply MP grease to the parts indicated by arrows.

(See page AT-14)



1. INSTALL CLIP, CONNECTING ROD SWIVEL, LOWER CONTROL SHAFT BUSHING, LOWER CONTROL SHAFT PIECE, PLATE WASHER AND SHIFT LEVER BOOT TO CONTROL LEVER

- (a) Install the shift lever boot, 2 plate washers, lower control shaft piece, lower control shaft bushing and connecting rod swivel to the control lever.
- (b) Using pliers, install the clip.




2. INSTALL CONTROL LEVER, SPACER AND CONTROL SHAFT

- (a) Connect the shift lever boot to the shift lever plate.


HINT:

Pull out the 3 lips of the shift lever boot securely, as shown in the illustration.



- (b) Install the control shaft and 2 spacers.
- (c) Install and torque the nut.

Torque: 13 N·m (128 kgf·cm, 9 ft·lbf)




3. INSTALL SHIFT LEVER SUB-ASSEMBLY


- (a) Install a new shift lever nut to the shift lever sub-assembly.

HINT:

Insert the shift lever nut securely until it fits and check there is no looseness.



- (b) Install the shift lever sub-assembly.
- (c) Using a pin punch and hammer, drive in the pin.




4. INSTALL SHIFT LOCK CONTROL UNIT ASSEMBLY

- (a) Connect the shift lock solenoid link and install a new slotted spring pin.
- (b) Install the compression spring to the shift lock solenoid link.
- (c) Push and install the shift lock solenoid link with the compression spring to the shift lock control unit assembly.
- (d) Install the shift lock control unit assembly.

HINT:

Do not torque the shift lock control unit assembly set screws.




5. INSTALL SHIFT LOCK PLATE STOPPER

- (a) Install the shift lever anti-rattle cushion and shift lock plate stopper cap to the stopper.
- (b) Install the stopper to the shift lever plate.


HINT:

- Check that the claw of the shift lock plate stopper firmly fits in and slides smoothly.
- Insert and connect the projection of the shift lock plate stopper into the square hole of the shift lock control unit assembly.



6. INSTALL NO.1 SHIFT LOCK SWITCH PLATE


- (a) Install the shift lever anti-rattle cushion to the roller.
- (b) Install the roller and shift lever anti-rattle cushion to the plate.



- (c) Install the No.1 shift lock switch plate in the direction shown in the illustration and lower to the direction shown by an arrow.


HINT:

Connect the groove of the No.1 shift lock switch plate to the projection of the shift lock control unit assembly.




7. INSTALL AND TORQUE 2 SHIFT LOCK CONTROL UNIT ASSEMBLY SET SCREWS

Torque: 2.0 N·m (20 kgf·cm, 17 in.·lbf)




8. INSTALL SPRING HOLDER AND SHIFT LEVER TORSION SPRING

(a) Install the shift lever torsion spring.



(b) Install the spring holder.




9. INSTALL SHIFT LEVER DETENT PIN, SHIFT LEVER SPRING DAMPER AND COMPRESSION SPRING TO SHIFT LEVER SUB-ASSEMBLY

10. ASSEMBLE INDICATOR LAMP SUB-ASSEMBLY

(a) Install the terminals of the indicator lamp wire sub-assembly to the connector.


(b) Install the bulb to the indicator lamp wire sub-assembly.



11. INSTALL SHIFT LEVER GUIDE HOUSING AND INDICATOR LAMP SUB-ASSEMBLY

(a) Install the indicator lamp sub-assembly to the shift lever guide housing.


(b) Install the shift lever housing with the indicator lamp sub-assembly to the shift lever plate.



- (c) Connect the indicator lamp wire sub-assembly to the shift lever plate.

HINT:

Hook the indicator lamp wire sub-assembly securely on the retainer of the shift lock plate.




12. INSTALL SHIFT LOCK RELEASE LINK AND SPRING

- (a) Install the shift lock release spring to the shift lock release link.
 (b) Install the 2 shift lever housing set bolts, nuts, shift lock release link and spring.
 (c) Torque the 2 nuts.

Torque: 3.9 N·m (40 kgf·cm, 35 in.-lbf)


13. INSTALL SLIDE COVER



14. INSTALL POSITION INDICATOR LENS TO POSITION INDICATOR HOUSING

HINT:

Fit the 4 claws of the position indicator lens in the grooves of the position indicator housing securely.




15. INSTALL POSITION INDICATOR HOUSING

- (a) Install the shift lock release button to the position indicator housing.
 (b) Install the position indicator housing to the shift lever plate.

HINT:

Fit the 4 clips of the position indicator housing in the shift lever plate securely.



16. INSTALL WIRE PROTECTOR TO SHIFT LEVER PLATE

17. INSTALL SHIFT LEVER KNOB