

DTC	B1262 / 62	A/C ECU communication stop
------------	-------------------	-----------------------------------

CIRCUIT DESCRIPTION


This DTC is output when communication stops between ECM and Body No.1 ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1262/62	No communication from ECU more than 10 seconds.	<ul style="list-style-type: none">• A/C ECU• Wireharness

WIRING DIAGRAM

[See page DI-820](#)

1 Check wireharness



PREPARATION:

Disconnect connector of "M3" of multi display (or "T5" tilt and telescopic ECU) "A13" of A/C ECU and "E7" (or "E5") of Engine and ECT ECU.

CHECK:

- Check continuity between terminals MPX+ of A/C ECU and MPX2 of Engine and ECT ECU.
- w/Navigation system
Check continuity between terminals MPX1 of multi display and MPX- of A/C ECU.
- w/o Navigation system
Check continuity between terminals MPX1 of tilt and telescopic ECU and MPX- of A/C ECU.

OK:

There is a continuity in wireharness of both (a) and (b) or (a) and (c), (a) or either (b) or (c).

HINT:

If there is OPEN in wireharness of either (a), (b) or (c), please repair it.

NG

Repair or replace wireharness.

OK

Replace the A/C ECU.