



Diagnosis Circuit

CIRCUIT DESCRIPTION

This circuit sends a signal to the ECU that DTC output is required.

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check voltage between terminals Tc and E1 of DLC3.****PREPARATION:**

Turn ignition switch ON.

CHECK:

Measure voltage between terminals SIL(7) and CG(4) of DLC3.

OK:

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown in problem/symptoms table (See page DI-604).

NG

2 Check wireharness and connector between DLC3 and body ECU No. 1, DLC3 and body ground (See page IN-30).

NG

Repair or replace wireharness or connector.

OK

Check and replace body ECU No. 1 (See page DI-604).