

SERVICE HINTS

L1 LUGGAGE COMPARTMENT DOOR OPENER SW

1-2 : Closed with the luggage compartment door open

B5 (A) BODY ECU NO.1

1-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position

4, 8-GROUND : Always approx. **12** volts

(A)15-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position

(A)17-GROUND : Continuity with luggage compartment door open

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B5	A	J10	74 (LHD)	L1	74 (LHD)
J7	74 (LHD)	J13	74 (LHD)	L5	78 (LHD)
J8	74 (LHD)	J16	74 (LHD)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1H	59 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
2B	60 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	60 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)
2G	61 (LHD)	

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IF	98 (LHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel

