

DISASSEMBLY

1. REMOVE THESE PARTS:

- (a) Luggage compartment door trim
- (b) Pull handle

2. REMOVE DOOR LOCK STRIKER

- (a) Remove the 2 bolts.
- (b) Remove the door lock striker.

3. REMOVE DOOR LOCK CYLINDER

- (a) Remove the 2 bolts.
- (b) Disconnect the connector.
- (c) Disconnect the link and remove the door lock cylinder.

4. REMOVE THESE PARTS:

- (a) Door lock
- (b) Rear stop light
- (c) License plate
- (d) License plate light