

When the cruise control main switch is turned ON, CRUISE MAIN indicator light lights up.

Cruise Control Indicator
(in Combination Meter)

Driver Side J/B

Ignition Switch

Engine Room No.1 RIB

Driver Side J/B

Battery

J18 (*1)
J37 (*2)
J/C

(*1) A
(*2) B

(*2)

(*1)

A
A
W-B

IF

II

(*1): LHD models
(*2): RHD models

INSPECTION PROCEDURE

1	Check combination meter (See Pub. No. RM588E on page BE-105).
---	---

NG

Replace combination meter.

OK

Check and replace engine and ECT ECU (See page IN-30).