



BO0V8-02

SLIDING ROOF ON-VEHICLE INSPECTION

INSPECT SLIDING ROOF GLASS ALIGNMENT

- (a) Start the engine and check the operation time of the sliding roof.

Operation time:

Approx. 6 secs.

- (b) Check for abnormal noise or binding during operation.
(c) With the sliding roof fully closed, check for water leakage.
(d) Check for a difference in level between the sliding roof weatherstrip and roof panel.

Front End :

-0.5 ± 1.5 mm (-0.020 ± 0.059 in.)

Center Line :

0 ± 1.5 mm (0 ± 0.059 in.)

Rear End :

0.5 ± 1.5 mm (0.020 ± 0.059 in.)