



## CIRCUIT DESCRIPTION

# WIRING DIAGRAM



**1 Check voltage between terminals +B and GND of ECU connector**




OK

LEXUS GS300 (RM588E)

NG

2 Check continuity between terminal GND of ECU connector and body ground.

**CHECK:**

Measure resistance between terminal GND of ECU connector and body ground.

**OK:**

Resistance: 1 kΩ or less

NG

Repair or replace harness or connector.

OK

3 Check P/SEAT fuse.

**PREPARATION:**

Remove P/SEAT fuse from passenger side J/B.

**CHECK:**

Check continuity of P/SEAT fuse.

**OK:**

Continuity

NG

Check for short in harness and all components connected to P/SEAT fuse.

OK

Check for open in harness and connector between ECU and battery. (See page N-29)