

## 29. CD MAGAZINE CANNOT BE INSERTED

### INSPECTION PROCEDURE

**1** Is CD magazine already inserted?

**YES**

Eject CD magazine.

**NO**

**2** Is auto search button of radio operating normally?

**YES**

Go to step 6.

**NO**

**3** Check if RADIO No. 1 fuse is OK?

**NG**

Replace RADIO No. 1 fuse.

**OK**

**4** Is power supplied to +B terminal of stereo component amplifier?

**NO**

+B wire harness faulty.

**YES**

**5** Check if GND (wire harness side) of radio receiver assembly.

**NG**

**+B wire harness faulty.**

**OK**

**Radio assembly faulty.**

**6** Is power supplied to +B terminal of CD auto changer?

**No**

**Radio receiver assembly faulty.**

**YES**

**7** Check if GND (wire harness side) of CD auto changer grounded normally?

**NG**

**Radio receiver assembly faulty.**

**OK**

**CD auto changer faulty.**