

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Sliding roof control system does not operate.	1. /ROOF Fuse 2. ECU-IG Fuse 3. Sliding Roof Control Switch Circuit 4. Sliding Roof Gear Assembly with ECU circuit	BE-21 BE-21 DI-607 DI-605
Sliding roof operates abnormally or stops half way.	1. Sliding Roof Pulse Plate Circuit	DI-610
Jam protection system does not operate.	1. Sliding Roof Gear Assembly with ECU circuit	DI-605