

REMOVAL

1. **REMOVE NO.1 ENGINE UNDER COVER**
2. **DRAIN ENGINE COOLANT**
3. **REMOVE AIR CLEANER INLET**
4. **REMOVE RESERVOIR TANK**
 - (a) Disconnect the upper reservoir tank hose.
 - (b) Disconnect the lower reservoir tank hose.
 - (c) Remove the 2 bolts and reservoir tank.
5. **REMOVE ELECTRIC COOLING FAN**
 - (a) Remove the upper radiator hose.
 - (b) Disconnect the engine ECU outlet duct from the fan shroud.
 - (c) Disconnect the 2 electric cooling fan connector.
 - (d) Disconnect the wire for the electric cooling fan from the clamps on the electric cooling fan.
 - (e) Remove the 6 bolts and electric cooling fan.

