

Sliding Roof Pulse Plate Circuit

WIRING DIAGRAM

See page DI-605.

INSPECTION PROCEDURE

HINT:

If there is not the LEXUS hand-held tester, begin with STEP 2.

1	Check sliding roof control switch operation. (See page DI-607 on step 1)
---	--

NG

Check sliding roof control switch circuit (See page DI-607).

OK

2	Check sliding roof pulse plate operation.
---	---

PREPARATION:

- (a) Connect the LEXUS hand-held tester to the DLC3.
- (b) Turn ignition switch ON and LEXUS hand-held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the LEXUS hand-held tester.


CHECK:

- (a) Operate the slide roof as the LEXUS hand-held tester directs.
- (b) At this time, check that status (ON/OFF) of pulse plate No.1 and No.2 changes on the LEXUS hand-held tester screen as shown in the chart below.

NOTICE:

Caution is necessary for a part of body not to be caught in as the jam protection system does not operate during conducting ACTIVE TEST.

OK:



NG

Replace sliding roof gear assembly.

OK

**3 Check sliding roof motor status.****PREPARATION:**

Connect the LEXUS hand-held tester to the DLC3.

**CHECK:**

- (a) Enter into ACTIVE TEST mode of LEXUS hand-held tester.
- (b) Check that "Sliding Roof" operates as the LEXUS hand-held tester directs.
- (c) At this time, check that motor status changes on the screen of LEXUS hand-held tester as the sliding roof switch of the vehicle is turned.

**OK:**

The motor operates normally.

NG

Replace sliding roof gear assembly.

OK

**4 Check sliding roof glass alignment. (Mechanical malfunction) (See page BO-74).**

NG

Adjust sliding roof (See page BO-81).

OK

Replace sliding roof gear assembly.