


SLIP Indicator Light Circuit

CIRCUIT DESCRIPTION

The SLIP indicator blinks during TRC & VSC operation.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

1	Check operation of the SLIP indicator light.
---	--

PREPARATION:

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the hand-held tester.

CHECK:

Check that "ON" and "OFF" of the SLIP indicator light can be shown on the combination meter with the hand-held tester.

OK

Go to step 4.

NG

- 2 Check that the SLIP indicator light is ON for 3 seconds soon after ignition switch is turned ON.

OK

Check and replace ABS & TRC & VSC ECU.

NG

- 3 Check SLIP indicator light.

See Combination Meter Troubleshooting on page BE-3.

NG

Repair or replace combination meter. Check and replace ABS & TRC & VSC ECU.

OK

- 4 Check for open and short circuit in harness and connector between ABS & TRC & VSC ECU and SLIP indicator light (See page IN-29).

NG

Repair or replace harness or connector.

OK

Check and replace ABS & TRC & VSC ECU.