

ABBREVIATIONS

The following abbreviations are used in this manual.

ABS	= Anti-Lock Brake System
A/C	= Air Conditioner
ACIS	= Acoustic Control Induction System
A/T	= Automatic Transmission
CD	= Compact Disc
COMB.	= Combination
EC	= Electrochromic
ECT	= Electronically Controlled Transmission
ECU	= Electronic Control Unit
EFI	= Electronic Fuel Injection
ESA	= Electronic Spark Advance
ETCS-i	= Electronic Throttle Control System Intelligent
EVAP	= Evaporative Emission
G.C.C.	= Gulf Cooperation Council
HID	= High Intensity Discharge
IC	= Integrated Circuit
J/B	= Junction Block
LED	= Light Emitting Diode
LH	= Left-Hand
LHD	= Left-Hand Drive
MPX	= Multiplex
O/D	= Overdrive
PPS	= Progressive Power Steering
R/B	= Relay Block
RH	= Right-Hand
RHD	= Right-Hand Drive
SRS	= Supplemental Restraint System
SW	= Switch
TEMP.	= Temperature
TRC	= Traction Control
VSC	= Vehicle Stability Control
VSV	= Vacuum Switching Valve
w/	= With
w/o	= Without

*The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.