

ENGINE (3UZ-FE)

HOW TO PROCEED WITH TROUBLESHOOTING

DI4DW-18

When using hand-held tester, troubleshooting in accordance with the procedure on the following page.

