

DTC	B1272 / 72	Power seat ECU communication stop (w/ Seat memory vehicle only)
-----	------------	--

CIRCUIT DESCRIPTION

This DTC is output when communication stops between power seat ECU and Body No.1 ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1272/72	No communication from seat ECU more than 10 seconds.	• Power seat ECU • Wireharness

WIRING DIAGRAM

See [page DI-816](#)

INSPECTION PROCEDURE

1	Check power seat ECU.
---	-----------------------


CHECK:

Check that the operation of front vertical and rear vertical is normal.


HINT:

With this inspection, the power seat ECU CPU can be diagnosed if it works normally or not.

NG	Replace the power seat ECU.
----	-----------------------------



2 Check wireharness



PREPARATION:

Disconnect connector "R13" of rear right door ECU, "P19" of power seat ECU and "R12" of rear left door ECU.

CHECK:

- Check continuity between terminals MPX1 of rear right door ECU and MPX2 of power seat ECU.
- Check continuity between terminals MPX1 of power seat ECU and MPX2 of rear left door ECU.

OK:

There is a continuity in wireharness of both (a) and (b), or either (a) or (b).

HINT:

If there is OPEN in wireharness of either (a) or (b), please repair it.

NG

Repair or replace wireharness.

OK

Replace power seat ECU.