


DTC	B2610	Tilt Position Sensor or Tilt Motor circuit Mal-function
------------	--------------	--



CIRCUIT DESCRIPTION


Tilt Motor is operated by the Power voltage supplied from Tilt and Telescopic ECU and makes the steering column tilt upward and downward. Tilt Position Sensor (Hole IC) in the Tilt and Telescopic ECU detects the tilt of the steering column and outputs the signal to the CPU in response to that tilt.

HINT:

Limit positions can be confirmed on the screen of the hand-held tester.

DTC No. (See Page)	Detection Item	Trouble Area
B2610	During tilt function operation, tilt operation stops within the operation range.	<ul style="list-style-type: none"> • Actuator Power Source circuit • Tilt Motor circuit • Tilt and Telescopic ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check Actuator Power Source circuit. (See page DI-373)

NG

Repair or replace.

OK

2 Check Tilt Motor circuit. (See page DI-375)

NG

Repair or replace.

OK

Check and replace the Tilt and Telescopic ECU.