



**Australian Government**

---

**Civil Aviation Safety Authority**

**TRAINING & EXAMINATION WORKBOOK**  
**for**  
**ATPL (Aeroplane) WEIGHT & BALANCE SYLLABUS**  
**Version 1 - 01 July 2011**

*[formerly part of ATPL Work Booklet]*

The Civil Aviation Safety Authority (CASA) owns copyright of this workbook.

The workbook is only for the use in training to the ATPL aeronautical knowledge (loading) syllabus of training and the associated CASA ATPL examinations, and not to be used for any other purpose.

After use in a CASA ATPL examination, the workbook must not be removed from the examination room but left with the CASA CyberExams supervisor for destruction. Failure to comply with these instructions may give CASA grounds for taking action against the candidate under CAR 298A, which action could lead to the outcome indicated in CAR 298A (5).

# **WEIGHT AND BALANCE**

## **IMPORTANT NOTE**

The weight and balance information contained in this Workbook is different from those in the (blue cover) Boeing 727 Performance & Operating Handbook used for calculating take-off & landing performance and fuel planning.

Use the data here for ONLY training to the ATPL weight & balance syllabus and ONLY in CASA ATPL weight & balance exams.

## **TABLE OF CONTENTS**

<b>CONTENT</b>	<b>PAGE</b>
STRUCTURAL LIMITING WEIGHTS	2
MAXIMUM ALLOWABLE NUMBER OF PASSENGERS	2
COMPARTMENT CAPACITIES AND LOADING LIMITATIONS	2
A. Forward Cargo Hold	
B. Aft Cargo Hold	
DEFINITIONS	3
A. Empty Weight	
B. Operational Items	
C. Basic Weight	
D. Maximum Zero Fuel Weight	
E. Index Unit	
F. Fuel Load	
G. Taxi Fuel or Taxi Allowance	
H. Take-off Fuel	
I. Trip Fuel	
CONFIGURATION LIST	4
VARIATIONS TO OPERATIONAL ITEMS	4
A. Life Vests	
B. Life Raft and Emergency Beacons	
C. APU Removed	
D. Other Approved Items	
FUEL MANAGEMENT	5
A. Useable Fuel Data	
B. Fuel Loading	
C. Fuel Usage	
D. Operation with Inoperative aft fuel boost pump in Tank 2	
LOADING GUIDE	9
Ballast Requirements	
STANDARD PASSENGER WEIGHTS	11
LOADING SYSTEMS	
Use of the Load and Trim Sheet	12 – 13
Use of Last Minute Passenger Adjustments	13
Sample Load and Trim Sheet	14
Blank Load & Trim Sheet	15

## SECTION 6 - WEIGHT & BALANCE

### 1. STRUCTURAL LIMITING WEIGHTS

MAXIMUM TAXI WEIGHT (RAMP)	89,675 KG
MAXIMUM TAKE-OFF WEIGHT (MBRW)	89,357 KG (*1)
MAXIMUM IN-FLIGHT WEIGHT:	
FLAPS 25	88,450 KG
FLAPS 30	73,028 KG
FLAPS 40	65,090 KG
MAXIMUM LANDING WEIGHT:	
FLAPS 30	72,574 KG
FLAPS 40	64,636 KG
MAXIMUM ZERO FUEL WEIGHT	63,502 KG

\*1 Apply a linear reduction of 50 KG for each 1,000 ft airport pressure altitude above 2,000'.

The above design maximum weights may be reduced for a particular flight because of considerations such as pavement strength requirements and take-off performance characteristics.

### 2. MAXIMUM ALLOWABLE NUMBER OF PASSENGERS

The basic Passenger Capacity of the Boeing 727 - comprising adults, adolescents (13 – 16 years), children (4 - 12 years) and infants (0 - 3 years) IN ANY COMBINATION but excluding Cabin crew, Technical crew and anyone occupying any extra seats is 138. Cabin crew (standard) is 6.

The standard zone/row relationship for the passenger cabin is as follows:

Total seats	Zone A	Zone B	Zone C	Zone D	Zone E
144	Rows 1-6	Rows 7-12	Rows 13-17	Rows 18-22	Rows 23-27

### 3. COMPARTMENT CAPACITIES AND LOADING LIMITATIONS

#### A. Forward Cargo Hold

Limitation	Compartment 1	Compartment 2	Total
Volume (cu. m)	7.8	6.9	14.7
Max Floor Loading (KG/m <sup>2</sup> )	----- 732 -----		
Max Running Load (KG/m run)	----- 839 -----		
Max Compartment Load (KG)	2273	1809	4082

#### B. Aft Cargo Hold

Limitation	Compartment 4	Compartment 5	Total
Volume (cu. m)	8.0	7.3	15.3
Max Floor Loading (KG/m <sup>2</sup> )	----- 732 -----		--
Max Running Load (KG/m run)	714	535	--
Max Compartment Load (KG)	1827	1801	3628

**4. DEFINITIONS****A. Empty Weight**

The empty weight of the aircraft includes equipment which has a fixed location and is actually on the aircraft when it is weighed.

**B. Operational Items**

These are added to the Empty Weight to obtain the Basic Weight. They are an assessment of normal items expected on each revenue flight e.g. cockpit documentation, cabin equipment, etc. This INCLUDES Crew and Galley provisions.

**C. Basic Weight**

Basic Weight is the Empty Weight plus Operational Items for a DOMESTICALLY configured aircraft. This does NOT include fuel or payload.

**D. Maximum Zero Fuel Weight**

The Maximum Zero Fuel Weight is the maximum weight the loaded aircraft is permitted to weigh before useable fuel is added. Any weight in excess of the Maximum Zero Fuel Weight MUST consist of useable fuel only.

**E. Index Unit**

(1) An Index Unit is a simplified way of writing a moment. It is defined as:

$$\text{IU} = \frac{\text{WEIGHT OF ITEM} \times \text{DISTANCE OF ITEM FROM CG DATUM}}{\text{CONSTANT}}$$

(2) Index Unit adjustments can be positive (+) or negative (-). This depends on whether the item is in front of or behind the CG datum (which is just forward of the main landing gear) and whether it is added to or removed from the aircraft. If the adjustment tends to move the CG forward (give the aircraft a nose-down effect) then the adjustment is negative; the adjustment is positive if the result is a nose-up effect.

**F. Fuel Load**

The total amount of fuel loaded on the aircraft.

**G. Taxi Fuel or Taxi Allowance**

The amount of fuel consumed from engine start to lining up for take-off. A standard allowance of 150 KG is used.

**H. Take-off Fuel**

The amount of fuel on board less the fuel consumed before the take-off run i.e. Fuel Load less Taxi Fuel.

**I. Trip Fuel**

The amount of fuel planned to be consumed from take-off to the station of first intended landing plus 400 KG allowance for approach and manoeuvring.

## 5. CONFIGURATION LIST

The following table defines the configuration requirements for DOMESTIC and OVER WATER flights.

ITEM	CONFIGURATION	
	DOMESTIC	OVER WATER
PASSENGER LIFE VESTS	IN	IN
LIFE RAFTS	OUT	4
EMERGENCY BEACONS	OUT	2
ADDITIONAL AVIONICS	OUT	IN

## 6. VARIATIONS TO OPERATIONAL ITEMS

### A. Life Vests

Weight of Life Vests is included in the aircraft Basic Weight. If the vests are NOT carried, the adjustment is:

**SUBTRACT 104 KG FROM THE BASIC WEIGHT**

**ADD 3.2 IU TO THE BASIC INDEX**

### B. Life Rafts and Emergency Beacons

When life rafts and emergency beacons are carried for over water operations, (2 x 42 person life rafts, one emergency beacon in the forward cabin ceiling, and 2 x 42 person life rafts and one emergency beacon in the mid-cabin overhead lockers) the following adjustment applies:

**ADD 260 KG TO THE BASIC WEIGHT**

**SUBTRACT 23.0 IU FROM THE BASIC INDEX**

### C. APU Removed

For operations with the APU removed the following adjustment applies:

**SUBTRACT 214 KG FROM THE BASIC WEIGHT**

**SUBTRACT 2.0 IU FROM THE BASIC INDEX**

### D. Additional Avionics

To account for the effect of the additional avionics required for overseas operations, apply the following adjustment:

**ADD 64 KG TO THE BASIC WEIGHT**

**SUBTRACT 6.8 IU FROM THE BASIC INDEX**

### E. Other Approved Items

When other approved items are to be carried in the cabin observe the following:

- (1) Obtain the weight of the item (even if it has to be weighed).
- (2) Unless special authorisation is issued, a load of 87 KG per seat position must not be exceeded. This means if the item is bolted under a seat that seat cannot carry a passenger.

**NOTE:** Account for the item's weight in the appropriate cabin zone and include this weight when calculating the number of "equivalent adults".

## 7. FUEL MANAGEMENT

### A. Useable Fuel Data

The table below shows nominal useable fuel capacities for under wing refueling procedure (over wing fuel capacities for tanks 1 & 3 will be slightly less than shown). The fuel weights are based on a specific gravity of 0.79. Actual capacities will vary with fuel density.

LOCATION	WEIGHT		VOLUME (Litres)
	Pounds	Kilograms	
WING TANKS (1 & 3)	23,404	10,616	13,438
CENTRE TANK (2)	29,727	13,484	17,068
AFT AUXILIARY TANK	5,670	2,572	3,255
FWD AUXILIARY TANK	5,340	2,422	3,066
<b>TOTAL</b>	64,141	<b>29,094</b>	36,827


### B. Fuel Loading

- (1) The fuel load in tanks 1 and 3 must not differ by more than 1,000 lbs (454 KG).
- (2) Load tanks 1, 2 & 3 equally. Tanks must be loaded simultaneously.
- (3) If tanks 1 and 3 are full and additional fuel is required, continue to load tank 2.
- (4) Tanks 1 and 3 must be full and tank 2 must contain at least 10,000 lbs (4,536 KG) more fuel than either 1 or 3 before the aft auxiliary tank is loaded.
  - (a) Aft Auxiliary Tank - Normal Loading  
The aft auxiliary tank is normally loaded when the total fuel requirement exceeds the capacity of tanks 1, 2 and 3.
  - (b) Aft Auxiliary Tank - Alternative Loading  
The aft auxiliary tank may be loaded when the total fuel requirement exceeds 45,500 lbs (20,600 KG), i.e. tanks 1 and 3 full and 22,500 lbs (10,200 KG) in tank 2. In comparison with the normal sequence with (a) above, this alternative fuel loading sequence will result in an aftward CG shift of up to 140 IU.
- (5) All other tanks must be full before the forward auxiliary tank is loaded, except when forward auxiliary fuel is used as ballast (refer (3) page 10).
- (6) A tabular presentation of both the normal and alternative fuel loading sequences is shown in the table "NOMINAL DISTRIBUTION OF LOADED FUEL". The table indicates the fuel tank loads for various total fuel loads (see page 7).

- (7) The following instructions describe the method of determining the CG when there is fuel in the aft auxiliary tank and tank 2 is not full. This situation can occur either as a result of loading the aft auxiliary tank as in (4) (b) or when the fuel loaded in the aft auxiliary tank remains after a short sector flight.

The following example shows the method used to plot CG lines for a total fuel load of 23,000 KG with 21,000 KG in tanks 1, 2 and 3 and 2,000 KG in the aft auxiliary tank.

- Plot the total fuel weight of tanks 1, 2 and 3 in the normal manner on the Fuel Loading Curve. This will produce point "X" on the line "BC".
- The fuel weight of 2,000 KG in the aft auxiliary tank is now marked off from point "C" to intersect section "CD" of the Fuel Loading Curve to give its CG shift effect.
- Draw a vertical line representing the total fuel load (23,000 KG).
- From the point of intersection on "CD", [sub-para (b)] draw a line parallel to "BC" to intersect the total fuel load line at "Y". "Y" is then projected horizontally to the fuel reference line in the normal manner (sub-para (16) on page 13).



**NORMAL FUEL LOADING (lbs)**

<b>TOTAL FUEL LOAD</b>	<b>TANK No. 1</b>	<b>TANK No. 2</b>	<b>TANK No.3</b>	<b>AFT AUX TANK</b>	<b>FWD AUX TANK</b>
65,500	12,000	30,000	12,000	6000	5,500
64,000	12,000	30,000	12,000	6000	4,000
62,000	12,000	30,000	12,000	6000	2,000
60,000*	12,000	30,000	12,000	6000	--
58,000*	12,000	30,000	12,000	4000	--
56,000*	12,000	30,000	12,000	2000	--
54,000*	12,000	30,000	12,000	--	--
52,000*	12,000	28,000	12,000	--	--
50,000*	12,000	26,000	12,000	--	--
48,000*	12,000	24,000	12,000	--	--
46,000*	12,000	22,000	12,000	--	--
44,000	12,000	20,000	12,000	--	--
42,000	12,000	18,000	12,000	--	--
40,000	12,000	16,000	12,000	--	--
38,000	12,000	14,000	12,000	--	--
36,000	12,000	12,000	12,000	--	--
34,000	11,333	11,334	11,333	--	--
32,000	10,667	10,666	10,667	--	--
30,000	10,000	10,000	10,000	--	--
28,000	9333	9334	9333	--	--
26,000	8667	8666	8667	--	--
24,000	8000	8000	8000	--	--
22,000	7333	7334	7333	--	--
20,000	6667	6666	6667	--	--
18,000	6000	6000	6000	--	--
16,000	5333	5334	5333	--	--
14,000	4667	4666	4667	--	--
12,000	4000	4000	4000	--	--
10,000	3333	3334	3333	--	--
8000	2667	2666	2667	--	--
6000	2000	2000	2000	--	--

**\*ALTERNATE FUEL LOADING (lbs)**

<b>TOTAL FUEL LOAD</b>	<b>TANK No. 1</b>	<b>TANK No. 2</b>	<b>TANK No. 3</b>	<b>AFT AUX TANK</b>
60,000	12,000	30,000	12,000	6000
58,000	12,000	28,000	12,000	6000
56,000	12,000	26,000	12,000	6000
54,000	12,000	24,000	12,000	6000
52,000	12,000	22,000	12,000	6000
50,000	12,000	22,000	12,000	4000
48,000	12,000	22,000	12,000	2000
46,000	12,000	22,000	12,000	--

The above figures may vary slightly with fuel density and individual tank capacity.

**NOMINAL DISTRIBUTION OF LOADED FUEL**



**C. Fuel Usage**

- (1) Essentially equal fuel in tanks 1, 2 and 3: Use tank to engine feed.
- (2) Tank 2 quantity greater than tank 1 or 3 quantities:
  - (a) Use tank 2 fuel feed.
  - (b) When fuel in tanks 1, 2 and 3 essentially equal, operate tank to engine.
- (3) Fuel in aft auxiliary tank:
  - (a) Use tank 2 for all operations until not less than 8,000 lbs (3,629 KG) has been used and the main tanks are essentially equal.
  - (b) Use fuel from the aft auxiliary tank.
  - (c) When the aft auxiliary tank is empty follow procedure (2) above.
- (4) Fuel in forward auxiliary tank:
  - (a) Use tank 2 for all operations until not less than 8,000 lbs (3,629 KG) has been used and the main tanks are essentially equal.
  - (b) Use fuel from the forward auxiliary tank.
  - (c) When the forward auxiliary tank is empty use fuel from the aft auxiliary tank.
  - (d) When the aft auxiliary tank is empty follow procedure (2) above.

**D. Operation with Inoperative Aft Fuel Boost Pump in Tank 2**

- (1) If required to operate with the aft fuel boost pump inoperative in tank 2, a minimum of 12,000 lbs (5,443 KG) of fuel must be in the tank at all times.
- (2) The 12,000 lbs (5,443 KG) of fuel in tank 2 is unusable and must therefore be considered as ballast. When compiling the load and trim sheet, the following procedure must be used:
  - (a) The maximum zero fuel weight will be reduced by 5,443 KG to 58,057 KG.
  - (b) The "fuel load" figure on the right hand side of the trim sheet will show the total fuel on board [i.e. fuel load for the flight plus 5,443 KG].
  - (c) Obtain Taxi Weight CG position as normal. To obtain Zero Fuel Weight CG position, complete the loading scales at the top of the trim sheet as required, but move the resultant CG position to the left by 139 IU (on the Basic Index Scale at the top of the trim sheet) to account for the 5,443 KG of ballast fuel.
- (3) Fuel Loading / Fuel Usage  
Load fuel as per normal procedures. Fuel usage is as normal with the exception that 12,000 lbs (5,443 KG) of fuel in tank 2 must be considered unusable at all times.

## 8. LOADING GUIDE

### Ballast Requirements

When loading the aircraft ballast may be required if the CG is found to be outside the CG envelope.

- (1) The following table lists the amount of ballast required for a desired IU change using only one of three presented options. That is ballast may be:
- (a) Fuel in the forward auxiliary tank only, or
  - (b) Fuel in tank no. 2 only, or
  - (c) Deadweight in the forward cargo hold, compartment 1 only.


FUEL IN ADDITION TO FLIGHT PLANNING REQUIREMENTS			
IU CHANGE REQU'D	FUEL REQU'D IN FWD AUX TANK ONLY (lbs)	OR FUEL REQU'D IN TANK 2 ONLY (lbs)	OR BALLAST REQU'D COMPT 1 ONLY (kgs)
-20	640	1770	160
-40	1280	3530	320
-60	1920	5160	480
-80	2560	6880	640
-100	3200	8600	800
-120	3840	10320	960
-140	4460	12040	1120
-160	5100	13760	1280
-180	(Exceeds tank capacity)	15480	1440
-200	(Exceeds tank capacity)	17200	1600

- (2) The following graph is used when fuel in tanks 1, 2 and 3 **and** deadweight ballast in compartment 1 are used in combination to achieve a desired IU shift.

Example: Required IU shift = - 100 IU to bring aircraft inside aft CG limit.

Flight plan fuel load = 15,000 lbs.

From graph: If 10,000 lbs fuel ballast is carried above the 15,000 lbs fuel load then only 350 KG ballast is required in compartment 1.



- (3) The following requirements apply to paragraphs (1) and (2) above.

When fuel is loaded as ballast, it must be considered to be unusable at all times.

When compiling a load and trim sheet, the following procedures must be used:

- Before entering the trim scales of the load and trim sheet, increase the Basic Weight by the weight of the fuel loaded as ballast (unusable fuel) and adjust the Basic Index by the corresponding negative IU effect from paragraph (1) or (2).
- When entering the Fuel Loading grid, reduce the total fuel on board by the weight of unusable fuel.
- Show usable fuel only in the "Fuel Load" figure on the right hand side of the Load and Trim Sheet.
- If the fuel is loaded as ballast in the forward auxiliary tank, then the Maximum Zero Fuel Weight is limited to 52,163 KG plus ballast fuel.

## 9. STANDARD PASSENGER AND BAGGAGE WEIGHTS

ADULT	Male	86 KG
	Female	71 KG
	Standard	81 KG
ADOLESCENT (13 - 16 years)		62 KG
CHILD (4 -12 years)		45 KG
INFANT (0 - 3 years)		20 KG

### Notes:

1. All the above weights are inclusive of cabin baggage allowance.
2. Use of the standard adult weight (81 KG) is permitted. Using individual male and female weights will generally result in a lower total passenger weight. The mixing of Standard and Male/Female Adult weights on the same Load and Trim Sheet is **prohibited**.
3. Load and Trim Sheet use:
  - (a) The passenger scales are graduated on the basis of an adult passenger and are valid for Standard, Male and Female Adults.
  - (b) When children and adolescents are carried for **scale movement purposes** one child/adolescent is equivalent to half an adult. The correct weight must be accounted for in the weight column.
  - (c) For **scale movement purposes** infants are ignored. However the correct weight must be accounted for in the weight column.
4. It is not permissible to mix actual and standard weights on a flight, when obtaining either the total passenger or total baggage weight.
5. When it is felt that the passengers or their baggage, on any particular flight, do not fall into the “standard” category then ALL the passengers and/or baggage for that flight should be weighed.

**10. LOADING SYSTEM****Use of the Load and Trim Sheet**

- (1) The Basic Weight and Basic Index, for examination purposes, will be given in all circumstances, except where an adjusted Basic Weight and Basic Index are provided. Insert the appropriate values in the space provided at the lower left corner of the form.
- (2) If required, add any Variations to Operational Items to derive the adjusted Basic Weight and Basic Index. Transfer these figures to the space provided at the top of the form.
- (3) Enter the actual number of each type of passenger in the space provided on the left of the weight column on the top right hand side of the form. Calculate the number of equivalent adults to be used in the loading scales,  
(e.g. 12 adults / 3 adolescents / 5 children / 2 infants =  $12 + 1.5 + 2.5 + 0$  gives 16 equivalent adults).
- (4) Calculate the weight of the passengers in each Row Block and enter this figure in the appropriate weight column.
- (5) Enter each compartment weight in the weights column.
- (6) If there is extra crew enter 81 KG for each extra in the weight column.
- (7) Add the weights to obtain the Zero Fuel Weight: check this does not exceed the Maximum Zero Fuel Weight.
- (8) Enter Fuel Load and add to the Zero Fuel Weight to obtain Taxi Weight. Ensure that it does not exceed Maximum Taxi Weight (either structural or pavement limited).
- (9) Enter Taxi Fuel and subtract from Taxi Weight to obtain Take-Off weight. Ensure that it does not exceed Maximum Take-Off Weight (either structural, performance or pavement limited).
- (10) Enter Trip Fuel and subtract from Take-Off Weight to obtain Landing Weight. Ensure that it does not exceed Maximum Landing Weight (either structural, performance or pavement limited).
- (11) Enter the top scale with the Adjusted Basic Index and move vertically down to the first passenger scale.
- (12) Move, in the direction of the arrow, the number of “equivalent adults” calculated in (3). Then move vertically down to the next scale.
- (13) Continue to complete all the other scales **paying special attention to the scale units and direction.**
- (14) Draw a vertical line from this last scale down into the Weight vs CG envelope. The point where this line intercepts a horizontal line drawn at the Zero Fuel Weight represents the aircraft’s Zero Fuel CG position.

- (15) From the point where the line just drawn intercepts the Fuel Reference Line, draw an oblique line parallel to the guide lines on the grid.
- (16) Now enter the Fuel Loading Curve with the Fuel Load for the flight and draw a vertical line up until it intercepts the loading curve. (Note the exception to this procedure on page 6). From this intersection draw a horizontal line to intersect the oblique line on the fuel grid (15). From this intersection draw a vertical line down into the Weight vs CG envelope. The point where this line intercepts a horizontal line drawn at the Take-Off Weight represents the aircraft's CG position at Take-Off.
- (17) Follow the radiating % MAC down to the % MAC grid line and draw a vertical line down to the Horizontal Stabilizer Setting line and obtain the Stabilizer Setting for Take-Off for the relevant flap setting.
- (18) Record the % MAC / Flap Setting / Stab. Setting figures in the box at the lower right hand corner.






#### Use of Last Minute Passenger Adjustments

- (1) In the CG envelope, fine dotted lines are drawn indicating the number of "Last Minute Passenger Adjustments" that may be made without needing to re-do the entire load sheet. The B727 permits a maximum number of Last Minute Passenger Adjustments of 10, be it an increase or decrease, using this procedure.
- (2) To determine the MAXIMUM number of last minute passenger adjustments, plot both the positions of the Taxi state, 'T' and the Zero Fuel State, 'Z' of the aircraft in the CG envelope. If both 'T' and 'Z' are in the central area, then up to 10 Last Minute Passenger changes may accepted. If either 'T' or 'Z' is outside this central area, then the number of Last Minute Passenger Adjustments is restricted to that number permitted by the dotted line that encloses both 'T' and 'Z'. In the sample Load & Trim sheet on page 14, the MAXIMUM number of Last Minute Passenger Adjustments would be 8 passengers, being limited by the position of 'Z'.
- (3) If the last minute passenger adjustment, results in an increase in weight, ensure that no weight limitations have been exceeded.
- (4) If the actual number of Last Minute Passenger Adjustments is greater than that permitted by the load sheet, then the Load & Trim sheet is not valid and must be re-drawn.
- (5) If the number of Last Minute Passenger Adjustments is equal to or less than that permitted, then the aircraft may depart and there is no requirement to re-draw the Load & Trim sheet.

# B727 - 200 LONG RANGE

## LOAD & TRIM SHEET

ADJ BASIC INDEX	178	I.U.	ALL WT IN KG
ROWS 1 - 6	18/-/-/-		4 7 2 5 0
ROWS 7 - 12	22/3/-/-		1 4 5 8
ROWS 13 - 17	25/-/-/-		1 9 6 8
ROWS 18 - 22	27/3/4/-		2 2 0 5
ROWS 23 - 27	23/3/2/-		2 0 8 7
FWD COMPT 1	(MAX 2273)		2 1 5 9
FWD COMPT 2	(MAX 1900)		8 7 5
REAR COMPT 4	(MAX 182)		1 3 8 0
REAR COMPT 5	(MAX 182)		1 4 5 0
EXTRA CREW	1		1 6 8 3
ZERO FUEL WT	(MAX 63502)		8 1
+ FUEL LOAD			6 2 5 9 6
TAXI WT	(MAX 89675)		1 2 9 0 0
TAXI FUEL			7 5 4 9 6
TAKE-OFF WT	(MAX 89357)		- 1 5 0
- TRIP FUEL			7 5 3 4 6
LANDING WT	(MAX 72514)		- 4 8 6 4
			7 0 4 8 2



### FOR EXAM PURPOSES ONLY!

NOTES  
THE CENTRE OF GRAVITY MUST BE CHECKED AT BOTH  
(A) ZERO FUEL WEIGHT  
(B) TAXI WEIGHT

LOAD ADJUSTMENTS  
THE LAST MINUTE ADJUSTMENT LINES ALLOW FOR UP TO 10 PASSENGERS WITHOUT CHANGING THE STABILIZER TRIM SETTING. THE MAXIMUM PERMITTED IS DETERMINED BY THE DOTTED LINES. THESE ADJUSTMENTS ARE FOR THE TAXI AND ZERO FUEL CENTRE OF GRAVITY POSITIONS.

### FUEL LOADING CURVE

PAYLOAD ADJ  
FINAL ZERO FUEL  
FINAL TAKE-OFF  
FINAL LANDING

I am satisfied that this aircraft has been loaded in accordance with Company requirements.	No. of Pass	
	Initial	Final
Signed	(Captain or F.O.)	
Prepared by	130	
MAXIMUM ALLOWABLE T.O.W. 89,357 KG.		
% MAC 25.3%	VH - ATP	
Flap Setting 20	Flt No. 418	
Stab. Setting 5.05	From SYD	
Date 21/09/XY	To MLB	

ITEM	WEIGHT	INDEX
BASIC AIRCRAFT	47250	178
ADJ. BASIC A/C	47250	178

# B727 - 200





# B727 - 200

ALL WT IN KG

**FOR EXAM  
PURPOSES  
ONLY!**

**NOTES**

**LOAD ADJUSTMENTS**  
THE LAST MINUTE ADJUSTMENT LINES ALLOW FOR UP TO 10 PASSENGERS WITHOUT CHANGING THE STABILIZER TRIM SETTING. THE MAXIMUM PERMITTED IS DETERMINED BY THE DOTTED LINES THAT ENCLOSE BOTH THE TAXI AND ZERO FUEL CENTRE OF GRAVITY POSITIONS.



ITEM	WEIGHT	INDEX
BASIC AIRCRAFT		
ADJ. BASIC A/C		

FLAP SETTING

7.5	7	6.5	6	5.5	5	4.5	4	3.5	3	15° & 20°	
8	7.5	7	6.5	6	5.5	5	4.5	4	3.5	3	25°

HORIZONTAL STABILIZER SETTING FOR TAKE OFF - NOSE UP

I am satisfied that this aircraft has been loaded in accordance with Company requirements.	No. of Pass	
	Initial	Final
Signed ..... (Captain or F.O.)	Prepared by .....	
MAXIMUM ALLOWABLE T.O.W. .... KG.		V.H. ....
% MAC .....	Flap Setting .....	Flt No. ....
Stab. Setting .....	From .....	To .....
Date .....	To .....	