

Engine Line (EL)

Command	Effect
Auto	Valves connected to EL are controlled by the control system
Manual	Valves connected to EL are manually controlled
Inert	Operate engine line inerting valve (V30) and vent valves GV1, GV2 and GV3.
Activate	Opens engine line gas valve (V27)
Close	Closing engine line gas valve (V27)
Emergency Stop	Will shut down BC, MGE, EL and Storage Tank
Reset	Reset trips and shutdowns
Close	Will close tank BC valve (V20)
Emergency Stop	Will shut down BC, MGE, EL and Storage Tank
Reset	Reset trips and shutdowns