

Main Gas Evaporator (MGE)

Command	Effect
Auto	Valves connected to MGE are controlled by the control system
Manual	Valves connected to MGE are manually controlled
Inert	Operates inert valve (V23) and EL vent valve (V26)
Activate	Will open Main Gas Evaporator valve (V22)
Close	Will close Main Gas Evaporator valve (V22)
Emergency Stop	Will shut down BC, MGE, EL and Storage Tank
Reset	Reset trips and shutdowns

Note! The Engine Line ventilation valve (V26) is also pressure controlled; opens at 7 bar and close at 6.5 bar.