

## Vapour Return Valve (VRL)

Command	Effect
Auto	Puts valves in vapour line to Auto control (V51 and V54)
Manual	Puts valves in vapour line to Manual control (V51 and V54)
Activate	Will open VRL discharge valve (V51)
Deactivate	Will close VRL discharge valve (V51)
Inert	Will operate inert valve (V04) and vent valve (V54)
Inert from Supplier	Will operate VRL discharge valve (V51) and vent valve (V54)
Inert to Supplier	Will operate inert valve (V04) and VRL discharge valve (V51)
Depressurize	Will open vent valve (V54). Note! Must be manually closed.
Select Bunker station 1	The valves (above listed) connected to VRL at bunker station 1 are controlled by the control system
Select Bunker station 2	The valves (above listed) connected to VRL at bunker station 2 are controlled by the control system