

Pressure Build Up Evaporator (PBE)

Command	Effect
Auto	Valves connected to PBE are controlled by the control system
Manual	Valves connected to PBE are manually controlled
Activate	The PBE Outlet Gas return valve (V16) will be controlled by the control system and open/close depending on tank pressure
Close	Will close the PBE Outlet Gas return valve (V16)
Emergency Stop	Will close PBE Outlet Gas return valve (V16)
Reset	Resets tripped PBE (PBE has to be reactivated)