

Gas Interconnection Line (GIL)

Command	Effect
Auto	Valves connected to GIL are controlled by the control system
Manual	Valves connected to GIL are manually controlled
Inert	Operate GIL inert valve (V29) and GIL ventilation valve (V25)
Activate	Will open GIL valve (V28) in both Pacs
Close	Will close GIL valve (V28) in both Pacs
Emergency Stop	Will shut down BC, MGE, EL and Storage Tank
Reset	Reset trips and shutdowns

Note! It's not possible to activate GIL if both engine lines (EL) are active. This may cause a change over to DO/HFO for the DGs, fed from the LNG Pac that is going to be closed down. Both EL and MGE have to be Closed before GIL activation is enabled.