

CPLD-Flashing:

1. make sure you have connected usbblaster JTAG header on platform and other end to hostmachine.
2. make sure you install qartus application `C:\intelFPGA_pro\18.1\qprogrammer\bin64`
3. make sure you give proper config path of the qartus application. Refer `cpld_sample_configuration.xml` available in dtaf core `data` folder.
4. refer `test_usbblaster_cpld_provider.py` for usage examples.
5. make sure during cpld main & secondary flashing you need to turn on the platform power.