

Postcode-Reading:

1. **Make Sure You Have Connected Usbblaster Jtag Header On Platform And Other End To Hostmachine.**
2. **1.Make Sure You Have Cpld Version 2vb.Pof Or Latest Version Flashed.**
3. **Make Sure You Install Qaurtus Application**  
**C:\Intelfpga\_Pro\18.1\Qprogrammer\Bin64**
4. **Make Sure You Give Proper Config Path Of The Qaurtus Application. Refer**  
**Postcode\_Usbblaster\_System\_Configuration.Xml** Available In Dtaf Core **Data**  
**Folder.**
5. **Create Folder In C: Drive Named Postcode, In That Extract The** **Postcode.Zip** **File.**  
**You Will See A Name Rfat\_Modified.Tcl**
6. **You Can Get The Postcode.Zip File From**  
**[\\Bdcspec010.Gar.Corp.Intel.Com\Os\\_Image](http://Bdcspec010.Gar.Corp.Intel.Com/Os_Image)** Or Dtaf\_Core Tools Location.
7. Refer **Test\_Usbblaster\_Physical\_Control\_Provider.Py** For Usage Examples.