

NAME

nitrocli – access Nitrokey devices

SYNOPSIS

nitrocli *command* [*arguments*]

DESCRIPTION

nitrocli provides access to Nitrokey devices. It supports the Nitrokey Pro and the Nitrokey Storage. It can be used to access the encrypted volume, the one-time password generator, and the password safe.

Device selection

Per default, **nitrocli** connects to any attached Nitrokey device. You can use the **--model**, **--serial-number** and **--usb-path** options to select the device to connect to. **nitrocli** fails if more than one attached Nitrokey device matches this filter or if multiple Nitrokey devices are attached and none of the filter options is set. Use the **list** command to list all attached devices with their USB path, model, and serial number (if available).

OPTIONS

-m, --model *pro|storage*

Restrict connections to the given device model, see the Device selection section.

--serial-number *serial-number*

Restrict connections to the given serial number, see the Device selection section. *serial-number* must be a hex string with an optional 0x prefix. This option can be set multiple times to allow any of the given serial numbers. Nitrokey Storage devices never match this restriction as they do not expose their serial number in the USB device descriptor.

--usb-path *usb-path*

Restrict connections to the given USB path, see the Device selection section.

--no-cache

If this option is set, nitrocli will not cache any inquired secrets using **gpg-agent**(1) but ask for them each time they are needed. Note that this option does not cause any cached secrets to be cleared. If a secret is already in the cache it will be ignored, but left otherwise untouched. Use the **pin clear** command to clear secrets from the cache.

-v, --verbose

Enable additional logging and control its verbosity. Logging enabled through this option will appear on the standard error stream. This option can be supplied multiple times. A single occurrence will show additional warnings. Commands sent to the device will be shown when supplied three times and full device communication is available with four occurrences. Supplying this option five times enables the highest verbosity.

-V, --version

Print the nitrocli version and exit.

COMMANDS**General**

nitrocli list [-n|--no-connect]

List all attached Nitrokey devices. This command prints a list of the USB path, the model and the serial number of all attached Nitrokey devices. To access the serial number of a Nitrokey Storage device, **nitrocli** has to connect to it. To omit the serial number of Nitrokey Storage devices instead of connecting to them, set the **--no-connect** option.

nitrocli status

Print the status of the connected Nitrokey device, including the stick serial number, the firmware version, and the PIN retry count. If the device is a Nitrokey Storage, also print storage related information including the SD card serial number, the encryption status, and the status of the volumes.

nitrocli lock

Lock the Nitrokey. This command locks the password safe (see the Password safe section). On the Nitrokey Storage, it will also close any active encrypted or hidden volumes (see the Storage section).

nitrocli reset

Perform a factory reset on the Nitrokey. This command performs a factory reset on the OpenPGP smart card, clears the flash storage and builds a new AES key. The user PIN is reset to 123456, the admin PIN to 12345678.

This command requires the admin PIN. To avoid accidental calls of this command, the user has to enter the PIN even if it has been cached.

Storage

The Nitrokey Storage comes with a storage area. This area is comprised of an *unencrypted* region and an *encrypted* one of fixed sizes, each made available to the user in the form of block devices. The encrypted region can optionally further be overlayed with up to four *hidden* volumes. Because of this overlay (which is required to achieve plausible deniability of the existence of hidden volumes), the burden of ensuring that data on the encrypted volume does not overlap with data on one of the hidden volumes is on the user.

nitrocli unencrypted set mode

Change the read-write mode of the volume. *mode* is the type of the mode to change to: **read-write** to make the volume readable and writable or **read-only** to make it only readable. This command requires the admin PIN.

Note that this command requires firmware version 0.51 or higher. Earlier versions are not supported.

nitrocli encrypted open

Open the encrypted volume on the Nitrokey Storage. The user PIN that is required to open the volume is queried using **pinentry**(1) and cached by **gpg-agent**(1).

nitrocli encrypted close

Close the encrypted volume on the Nitrokey Storage.

nitrocli hidden create slot start end

Create a new hidden volume inside the encrypted volume. *slot* must indicate one of the four available slots. *start* and *end* represent, respectively, the start and end position of the hidden volume inside the encrypted volume, as a percentage of the encrypted volume's size. This command requires a password which is later used to look up the hidden volume to open. Unlike a PIN, this password is not cached by **gpg-agent**(1).

nitrocli hidden open

Open a hidden volume. The volume to open is determined based on the password entered, which must have a minimum of six characters. Only one hidden volume can be active at any point in time and previously opened volumes will be automatically closed. Similarly, the encrypted volume will be closed if it was open.

nitrocli hidden close

Close a hidden volume.

nitrocli fill

Fills the SD card with random data, overwriting all existing data. This operation cannot be cancelled, even if the **nitrocli** process is terminated before it finishes.

This command requires the admin PIN. To avoid accidental calls of this command, the user has to enter the PIN even if it has been cached.

One-time passwords

The Nitrokey Pro and the Nitrokey Storage support the generation of one-time passwords using the HOTP algorithm according to RFC 4226 or the TOTP algorithm according to RFC 6238. The required data – a name and the secret – is stored in slots. Currently, the Nitrokey devices provide three HOTP slots and 15 TOTP slots. The slots are numbered per algorithm starting at zero.

The TOTP algorithm is a modified version of the HOTP algorithm that also uses the current time. Therefore, the Nitrokey clock must be synchronized with the clock of the application that requests the one-time password.

nitrocli otp get *slot* [-a|--algorithm *algorithm*] [-t|--time *time*]

Generate a one-time password. *slot* is the number of the slot to generate the password from. *algorithm* is the OTP algorithm to use. Possible values are **hotp** for the HOTP algorithm according to RFC 4226 and **totp** for the TOTP algorithm according to RFC 6238 (default). Per default, this command sets the Nitrokey's time to the system time if the TOTP algorithm is selected. If **--time** is set, it is set to *time* instead, which must be a Unix timestamp (i.e., the number of seconds since 1970-01-01 00:00:00 UTC). This command might require the user PIN (see the Configuration section).

nitrocli otp set *slot name secret* [-a|--algorithm *algorithm*] [-d|--digits *digits*] [-c|--counter *counter*] [-t|--time-window *time-window*] [-f|--format *ascii|base32|hex*]

Configure a one-time password slot. *slot* is the number of the slot to configure. *name* is the name of the slot (may not be empty). *secret* is the secret value to store in that slot.

The **--format** option specifies the format of the secret. If it is set to **ascii**, each character of the given secret is interpreted as the ASCII code of one byte. If it is set to **base32**, the secret is interpreted as a base32 string according to RFC 4648. If it is set to **hex**, every two characters are interpreted as the hexadecimal value of one byte. The default value is **base32**.

algorithm is the OTP algorithm to use. Possible values are **hotp** for the HOTP algorithm according to RFC 4226 and **totp** for the TOTP algorithm according to RFC 6238 (default). *digits* is the number of digits the one-time password should have. Allowed values are 6 and 8 (default: 6). *counter* is the initial counter if the HOTP algorithm is used (default: 0). *time window* is the time window used with TOTP in seconds (default: 30).

nitrocli otp clear *slot* [-a|--algorithm *algorithm*]

Delete the name and the secret stored in a one-time password slot. *slot* is the number of the slot to clear. *algorithm* is the OTP algorithm to use. Possible values are **hotp** for the HOTP algorithm according to RFC 4226 and **totp** for the TOTP algorithm according to RFC 6238 (default).

nitrocli otp status [-a|--all]

List all OTP slots. If **--all** is not set, empty slots are ignored.

Configuration

Nitrokey devices have four configuration settings: the numlock, capslock and scrollock keys can be mapped to an HOTP slot, and OTP generation can be set to require the user PIN.

nitrocli config get

Print the current Nitrokey configuration.

nitrocli config set [[-n|--numlock *slot*] | [-N|--no-numlock]] [[-c|--capslock *slot*] | [-C|--no-capslock]] [[-s|--scrollock *slot*] | [-S|--no-scrollock]] [[-o|--otp-pin] | [-O|--no-otp-pin]]

Update the Nitrokey configuration. This command requires the admin PIN.

With the **--numlock**, **--capslock** and **--scrollock** options, the respective bindings can be set. *slot* is the number of the HOTP slot to bind the key to. If **--no-numlock**, **--no-capslock** or **--no-scrollock** is set, the respective binding is disabled. The two corresponding options are mutually exclusive.

If **--otp-pin** is set, the user PIN will be required to generate one-time passwords using the **otp get** command. If **--no-otp-pin** is set, OTP generation can be performed without PIN. These two options are mutually exclusive.

Password safe

The Nitrokey Pro and the Nitrokey Storage provide a password safe (PWS) with 20 slots. In each of these slots you can store a name, a login, and a password. The PWS is not encrypted, but it is protected with the user PIN by the firmware. Once the PWS is unlocked by one of the commands listed below, it can be accessed without authentication. You can use the **lock** command to lock the password safe.

nitrocli pws get *slot* [-n|--name] [-l|--login] [-p|--password] [-q|--quiet]

Print the content of one PWS slot. *slot* is the number of the slot. Per default, this command prints the name, the login and the password (in that order). If one or more of the options **--name**, **--login**, and **--password** are set, only the selected fields are printed. The order of the fields never changes.

The fields are printed together with a label. Use the **--quiet** option to suppress the labels and to only output the values stored in the PWS slot.

nitrocli pws set *slot name login password*

Set the content of a PWS slot. *slot* is the number of the slot to write. *name*, *login*, and *password* represent the data to write to the slot.

nitrocli pws clear *slot*

Delete the data stored in a PWS slot. *slot* is the number of the slot clear.

nitrocli pws status [-a|--all]

List all PWS slots. If **--all** is not set, empty slots are ignored.

PINs

Nitrokey devices have two PINs: the user PIN and the admin PIN. The user PIN must have at least six, the admin PIN at least eight characters. The user PIN is required for commands such as **otp get** (depending on the configuration) and for all **pws** commands. The admin PIN is usually required to change the device configuration.

Each PIN has a retry counter that is decreased with every wrong PIN entry and reset if the PIN was entered correctly. The initial retry counter is three. If the retry counter for the user PIN is zero, you can use the **pin unblock** command to unblock and reset the user PIN. If the retry counter for the admin PIN is zero, you have to perform a factory reset using the **reset** command or **gpg(1)**. Use the **status** command to check the retry counters.

nitrocli pin clear

Clear the PINs cached by the other commands. Note that cached PINs are associated with the device they belong to and the **clear** command will only clear the PIN for the currently used device, not all others.

nitrocli pin set *type*

Change a PIN. *type* is the type of the PIN that will be changed: **admin** to change the admin PIN or **user** to change the user PIN. This command only works if the retry counter for the PIN type is at least one. (Use the **status** command to check the retry counters.)

nitrocli pin unblock

Unblock and reset the user PIN. This command requires the admin PIN. The admin PIN cannot be unblocked. This operation is equivalent to the unblock PIN option provided by **gpg(1)** (using the **--change-pin** option).

CONFIG FILE

nitrocli tries to read the configuration file at `${XDG_CONFIG_HOME}/nitrocli/config.toml` (or `${HOME}/nitrocli/config.toml` if the `XDG_CONFIG_HOME` environment variable is not set). It is used to set default values for the options listed below.

You can also set the environment variable **NITROCLI_KEY** to overwrite the configuration for *key* (see the Environment section). Note that command-line arguments overwrite both the configuration file and the environment variables.

The following values can be set in the configuration file:

model Restrict connections to the given device model (string, default: not set, see `--model`).

serial_numbers

Restrict connections to the given serial numbers (list of strings, default: empty, see `--serial-number`).

usb_path

Restrict connections to the given USB path (string, default: not set, see `--usb-path`).

no_cache

If set to true, do not cache any inquired secrets (boolean, default: false, see `--no-cache`).

verbosity

Set the log level (integer, default: 0, see `--verbose`).

The configuration file must use the TOML format, for example:

```
model = "pro"
serial_numbers = ["0xf00baa", "deadbeef"]
usb_path = "0001:0006:02"
no_cache = false
verbosity = 0
```

ENVIRONMENT

The program honors a set of environment variables that can be used to suppress interactive PIN entry through **pinentry**(1). The following variables are recognized:

NITROCLI_ADMIN_PIN

The admin PIN to use.

NITROCLI_USER_PIN

The user PIN to use.

NITROCLI_NEW_ADMIN_PIN

The new admin PIN to set. This variable is only used by the **pin set** command for the **admin** type.

NITROCLI_NEW_USER_PIN

The new user PIN to set. This variable is only used by the **pin set** command for the **user** type.

NITROCLI_PASSWORD

A password used by commands that require one (e.g., **hidden open**).

Additionally, these environment variables can be used to overwrite the configuration (see the Config file section):

NITROCLI_MODEL

Restrict connections to the given device model (string, default: not set, see `--model`).

NITROCLI_SERIAL_NUMBERS

Restrict connections to the given list of serial numbers (comma-separated list of strings, default: empty, see `--serial-number`).

NITROCLI_USB_PATH

Restrict connections to the given USB path (string, default: not set, see **--usb-path**).

NITROCLI_NO_CACHE

If set to true, do not cache any inquired secrets (boolean, default: false, see **--no-cache**).

NITROCLI_VERBOSITY

Set the log level (integer, default: 0, see **--verbose**).

FILES

\${XDG_CONFIG_HOME}/nitrocli/config.toml

\${HOME}/nitrocli/config.toml

User configuration file, see the Config file section.

EXAMPLES**Storage**

Create a hidden volume in the first available slot, starting at half the size of the encrypted volume (i.e., 50%) and stretching all the way to its end (100%):

```
$ nitrocli hidden create 0 50 100
```

One-time passwords

Configure a one-time password slot with a hexadecimal secret representation:

```
$ nitrocli otp set 0 test-rfc4226 3132333435363738393031323334353637383930 --algorithm hotp
```

```
$ nitrocli otp set 1 test-foobar 666F6F626172 --algorithm hotp
```

```
$ nitrocli otp set 0 test-rfc6238 3132333435363738393031323334353637383930 --algorithm totp
--digits 8
```

Configure a one-time password slot with an ASCII secret representation:

```
$ nitrocli otp set 0 test-rfc4226 12345678901234567890 --format ascii --algorithm hotp
```

```
$ nitrocli otp set 1 test-foobar foobar --format ascii --algorithm hotp
```

```
$ nitrocli otp set 0 test-rfc6238 12345678901234567890 --format ascii --algorithm totp --digits 8
```

Configure a one-time password slot with a base32 secret representation:

```
$ nitrocli otp set 0 test-rfc4226 gezdgnbvgy3tqojqgezdgnbvgy3tqojq --format base32 --algorithm
hotp
```

```
$ nitrocli otp set 1 test-foobar mzxw6ytboi===== --format base32 --algorithm hotp
```

```
$ nitrocli otp set 0 test-rfc6238 gezdgnbvgy3tqojqgezdgnbvgy3tqojq --format base32 --algorithm
totp --digits 8
```

Generate a one-time password:

```
$ nitrocli otp get 0 --algorithm hotp
```

```
755224
```

```
$ nitrocli otp get 0 --algorithm totp --time 1234567890
```

```
89005924
```

Clear a one-time password slot:

```
$ nitrocli otp clear 0 --algorithm hotp
```

Configuration

Query the configuration:

```
$ nitrocli config get
```

Config:

```
numlock binding:      not set
```

```
capslock binding:     not set
```

```
scrollock binding:    not set
```

```
require user PIN for OTP: true
```

Change the configuration:

```
$ nitrocli config set --otp-pin
```

Password safe

Configure a PWS slot:

```
$ nitrocli pws set 0 example.org john.doe passw0rd
```

Get the data from a slot:

```
$ nitrocli pws get 0  
name:  example.org  
login:  john.doe  
password: passw0rd
```

Copy the password to the clipboard (requires **xclip(1)**).

```
$ nitrocli pws get 0 --password --quiet | xclip -in
```

Query the PWS slots:

```
$ nitrocli pws status  
slot  name  
0      example.org
```