



# G-CAMP WORKSHOP

BUILD THE RIGHT THING  
BUILD THING RIGHT  
SHIP FAST

*Lecturer* Kim Myoung-Ho  
*Nickname* 불스  
blogstudy@naver.com

## 2강\_디바이스 연결

- 드라이버 다운로드 및 설치
- 펌웨어 다운로드 및 설치



## 2-1. 드라이버 다운로드 및 설치



USB연결

제조사 홈페이지 방문  
(st.com)

User manuals 참고

B-L475E-IOT01A

- 7.3.1 Drivers .....
- 7.3.2 ST-LINK/V2-1 firmware upgrade .

### Drivers

Before connecting STM32L475VG to a Windows® PC (XP, 7, 8 or 10) via USB, a driver for the ST-LINK/V2-1 must be installed. It is available at the [www.st.com](http://www.st.com) website.

Products ▾

ST-LINK/V2-1

Search

STSW-LINK009





## 2-2. 펌웨어 다운로드 및 설치



User manuals 참고

Part Number ▾	Status ▾	Type ▾	Category ▾	Description ▾
<a href="#">STSW-LINK007</a>	ACTIVE	Development Tools	Software Development Tools	ST-LINK, ST-LINK/V2, ST-LINK/V2-1, STLINK-V3 boards firmware upgrade
<a href="#">STSW-LINK009</a>	ACTIVE	Development Tools	Software Development Tools	ST-LINK, ST-LINK/V2, ST-LINK/V2-1 USB driver signed for Windows7, Windows8, Windows10
<a href="#">STSW-LINK008</a>	NRND	Development Tools	Software Development Tools	ST-LINK/V2-1 USB driver on Windows Vista, 7 and 8