



- c 1 Fold Seat Control ECU RH
- c 2 Fold Seat Control ECU RH
- c 3 No. 3 Seat Back Frame Sub-Assembly RH
- c 4 No. 2 Seat Cushion Frame Sub-Assembly RH

- d 1 Fold Seat Control ECU LH
- d 2 Fold Seat Control ECU LH
- d 3 No. 3 Seat Back Frame Sub-Assembly LH
- d 4 No. 2 Seat Cushion Frame Sub-Assembly LH
- d 5 No. 2 Seat Cushion Frame Sub-Assembly LH
- d 6 Junction Connector

Position of Parts in Seat <Rear No. 2 Seat>

