

## F RELAY LOCATIONS

---

[Seat]

(Front Seat)

Front Position Control ECU and Switch Assembly LH  
(Front Power Seat Switch LH)

