



R	3	Front Seat Outer Belt Assembly LH
R	4	Front Seat Outer Belt Assembly LH
R	6	Rear Side Airbag Sensor Assembly LH
R	7	Curtain Shield Airbag Assembly LH
R	9	Front Door Courtesy Light Switch Assembly LH
R	10	Rear Door Courtesy Light Switch Assembly LH
R	11	Back Door Courtesy Light Switch Assembly
R	14	Rear Power Seat Switch LH
R	15	No. 2 Fold Seat Switch Assembly
R	16	Rear Header Speaker Assembly LH
R	17	No. 2 Indoor Electrical Key Antenna Assembly
R	18	No. 3 Indoor Electrical Key Antenna Assembly
R	19	Outside Luggage Electrical Key Antenna
R	20	Door Control Receiver
R	21	Rear Acceleration Sensor Assembly
R	23	Stabilizer Control with Accumulator Housing Assembly
R	24	No. 1 Speaker with Box Assembly
R	25	Rear Combination Light Assembly LH
R	26	Rear Combination Light Assembly RH
R	28	Fuel Lid Motor Assembly
R	29	Rear Seat Outer Belt Assembly LH
R	30	Front Tension Reducer LH
R	31	Stereo Component Amplifier Assembly
R	32	Stereo Component Amplifier Assembly
R	33	Stereo Component Amplifier Assembly
R	34	Stereo Component Amplifier Assembly
R	35	No. 1 Interior Illumination Light Assembly LH
R	37	Junction Connector
R	38	Junction Connector
R	39	Junction Connector
R	40	Junction Connector
R	41	Junction Connector

Position of Parts in Body

