


REAR FLOOR PAN (ASSY)



F43886A


With the body lower back panel and rear floor side panel removed.

Symbol meaning


▲▲ : Remove Weld Points

F43321B


REMOVAL



[LH Side]



[RH Side]




F43321

REMOVAL POINT

- 1 Remove the rear floor side center panel at the same time.


Symbol meaning

⊙ : Spot Weld ⊙ I : Plug Weld  : Fillet Weld


F43322B

INSTALLATION

[Upper Face]




[Lower Face]




F43322

INSTALLATION POINT


- 1 Before temporarily installing the new parts, weld the rear floor side center panel, rear floor plate bracket and weld bolts with the standard number of welding points.



[LH Side]



[RH Side]



F43323

INSTALLATION POINT

- 1 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- 2 After welding, apply body sealer and undercoating to the corresponding parts. (See the paint-coating)
- 3 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.