


Position of Parts in Body <LHD 5-Door>



- E 1 Differential Lock Shift Actuator
- E 2 No. 1 Transfer Indicator Switch

- J 1 Front Power Window Regulator Switch Assembly RH
- J 2 Outer Rear View Mirror Assembly RH
- J 3 Outer Rear View Mirror Assembly RH
- J 4 Front No. 2 Speaker Assembly RH
- J 5 Front Door Courtesy Light Assembly RH
- J 6 Front Door with Motor Lock Assembly RH
- J 7 Front Power Window Regulator Motor Assembly RH
- J 8 Side Airbag Sensor Assembly RH

- K 1 Outer Rear View Mirror Assembly LH
- K 2 Outer Rear View Mirror Assembly LH
- K 3 Front No. 2 Speaker Assembly LH
- K 4 Multiplex Network Master Switch Assembly
- K 5 Front Door Courtesy Light Assembly LH
- K 6 Front Door with Motor Lock Assembly LH
- K 7 Front Power Window Regulator Motor Assembly LH
- K 8 Side Airbag Sensor Assembly LH
- K 9 Seat Memory Switch

- L 1 Rear Speaker Set RH
- L 2 Rear Power Window Regulator Switch Assembly RH
- L 3 Rear No. 2 Speaker Assembly RH
- L 4 Rear Power Window Regulator Motor Assembly RH
- L 5 Rear Door Lock Assembly RH

- M 1 Rear Speaker Set LH
- M 2 Rear Power Window Regulator Switch Assembly LH
- M 3 Rear No. 2 Speaker Assembly LH
- M 4 Rear Power Window Regulator Motor Assembly LH
- M 5 Rear Door Lock Assembly LH

- N 1 Electrical Key Antenna RH

- O 1 Electrical Key Antenna LH

- P 1 Front Side Step Light LH
- P 2 Front Side Step Light RH
- P 3 Rear Side Step Light LH
- P 4 Rear Side Step Light RH

Position of Parts in Body <LHD 5-Door>

