



ABSTRACT

This user's guide describes the characteristics, operation, and use of the TPS546B24AEVM-1PH evaluation module (EVM). The user's guide includes test information, descriptions, and results. A complete schematic diagram, printed-circuit board layouts, and bill of materials are also included in this document. Throughout this user's guide, the abbreviations EVM, TPS546B24AEVM-1PH, and the term evaluation module are synonymous with the TPS546B24AEVM-1PH, unless otherwise noted.

Table of Contents

1 Description	3
1.1 Before You Begin	3
1.2 Typical Applications	3
1.3 Features	4
2 Electrical Performance Specifications	5
3 Schematic	6
4 Test Setup	8
4.1 Test and Configuration Software	8
4.2 Test Equipment	8
4.3 Tip and Barrel Measurement	9
4.4 List of Test Points, Jumpers, and Connectors	9
4.5 Evaluating Split Rail Input	10
4.6 Configuring EVM to Overdrive VDD5	11
4.7 Powering from a Single 3.3-V Input Power Supply	11
5 EVM Configuration Using the Fusion GUI	12
5.1 Configuration Procedure	12
6 Test Procedure	13
6.1 Line and Load Regulation and Efficiency Measurement Procedure	13
6.2 Efficiency Measurement Test Points	13
6.3 Control Loop Gain and Phase Measurement Procedure	13
7 Performance Data and Typical Characteristic Curves	14
7.1 Efficiency	14
7.2 Load and Line Regulation (Measured Between TP27 and TP26)	14
7.3 Transient Response	15
7.4 Control Loop Bode Plot	15
7.5 Output Ripple	16
7.6 Power MOSFET Drain-Source Voltage	17
7.7 Control On	18
7.8 Control Off	18
7.9 Control On With Pre-biased Output	19
7.10 Thermal Image	19
8 EVM Assembly Drawing and PCB Layout	20
9 Bill of Materials	23
10 Using the Fusion GUI	25
10.1 Opening the Fusion GUI	25
10.2 General Settings	26
10.3 Changing ON_OFF_CONFIG	27
10.4 Pop-up for Some Commands While Conversion is Enabled	28
10.5 SMBALERT# Mask	29
10.6 Device Info	30

10.7 Phase Commands.....	31
10.8 All Config.....	32
10.9 Pin Strapping.....	33
10.10 Monitor.....	34
10.11 Status.....	35

List of Figures

Figure 3-1. TPS546B24AEVM-1PH Schematic - Main Circuit.....	6
Figure 3-2. TPS546B24AEVM-1PH Schematic - Connectors and Charge Pumps.....	7
Figure 4-1. Tip and Barrel Measurement.....	9
Figure 7-1. Efficiency.....	14
Figure 7-2. Load Regulation.....	14
Figure 7-3. Line Regulation.....	14
Figure 7-4. Transient Response.....	15
Figure 7-5. Bode Plot at 1.2-V Output at 12 VIN, 20-A Load.....	15
Figure 7-6. Output Ripple With 0-A Load.....	16
Figure 7-7. Output Ripple With 20-A Load.....	16
Figure 7-8. Low-side MOSFET VDS	17
Figure 7-9. High-side MOSFET VDS	17
Figure 7-10. Start-Up From Control, 20-A CC Load.....	18
Figure 7-11. Shutdown From Control, 20-A CC Load.....	18
Figure 7-12. Start-Up From Control With Pre-biased Output.....	19
Figure 8-1. TPS546B24AEVM-1PH 3D Top View.....	20
Figure 8-2. TPS546B24AEVM-1PH 3D Bottom View.....	20
Figure 8-3. TPS546B24AEVM-1PH Top Side Component View (Top View).....	20
Figure 8-4. TPS546B24AEVM-1PH Bottom Side Component View (Bottom View).....	20
Figure 8-5. TPS546B24AEVM-1PH Top Copper (Top View).....	21
Figure 8-6. TPS546B24AEVM-1PH Internal Layer 1 (Top View).....	21
Figure 8-7. TPS546B24AEVM-1PH Internal Layer 2 (Top View).....	21
Figure 8-8. TPS546B24AEVM-1PH Internal Layer 3 (Top View).....	21
Figure 8-9. TPS546B24AEVM-1PH Internal Layer 4 (Top View).....	22
Figure 8-10. TPS546B24AEVM-1PH Internal Layer 5 (Top View).....	22
Figure 8-11. TPS546B24AEVM-1PH Internal Layer 6 (Top View).....	22
Figure 8-12. TPS546B24AEVM-1PH Internal Bottom Layer (Top View).....	22
Figure 10-1. Select Device Scanning Mode.....	25
Figure 10-2. General Settings.....	26
Figure 10-3. Configure – ON_OFF_CONFIG.....	27
Figure 10-4. Pop-up When Trying to Change FREQUENCY_SWITCH With Conversion Enabled.....	28
Figure 10-5. Configure – SMBALERT # Mask.....	29
Figure 10-6. Configure – Device Info.....	30
Figure 10-7. Phase Commands.....	31
Figure 10-8. Configure – All Config.....	32
Figure 10-9. Configure – Pin Strapping.....	33
Figure 10-10. Monitor Screen.....	34
Figure 10-11. Status Screen.....	35

List of Tables

Table 2-1. TPS546B24AEVM-1PH Electrical Performance Specifications.....	5
Table 4-1. Test Point Functions.....	9
Table 4-2. Jumpers.....	10
Table 4-3. JP4 Selections.....	10
Table 4-4. JP3 Selections.....	10
Table 4-5. Connector Functions.....	10
Table 6-1. Test Points for Efficiency Measurements.....	13
Table 6-2. List of Test Points for Loop Response Measurements.....	13
Table 9-1. Bill of Materials.....	23

Trademarks

All other trademarks are the property of their respective owners.

1 Description

The TPS546B24AEVM-1PH evaluation module uses the TPS546B24A device in a buck design. It is designed for a nominal 12-V bus and to produce a regulated 1.2-V output at up to 20 A of load current. The TPS546B24AEVM-1PH provides a number of test points to evaluate the performance of the device.

1.1 Before You Begin

The following warnings and cautions are noted for the safety of anyone using or working close to the TPS546B24AEVM-1PH. Observe all safety precautions.



Warning

The TPS546B24AEVM-1PH circuit module may become hot during operation due to dissipation of heat. Avoid contact with the board. Follow all applicable safety procedures applicable to your laboratory.



Caution

Do not leave the EVM powered when unattended.

WARNING

The circuit module has signal traces, components, and component leads on the bottom of the board. This may result in exposed voltages, hot surfaces, or sharp edges. Do not reach under the board during operation.

CAUTION

The circuit module may be damaged by over temperature. To avoid damage, monitor the temperature during evaluation and provide cooling, as needed, for your system environment.

CAUTION

Some power supplies can be damaged by application of external voltages. If using more than 1 power supply, check your equipment requirements and use blocking diodes or other isolation techniques, as needed, to prevent damage to your equipment.

CAUTION

The communication interface is not isolated on the EVM. Be sure no ground potential exists between the computer and the EVM. Also be aware that the computer is referenced to the battery- potential of the EVM.

1.2 Typical Applications

The TPS546B24A device is designed for the following applications:

- High-density power solutions
- Wireless infrastructure
- Switcher
- Router network
- Server
- Storage
- Smart power systems

1.3 Features

This EVM has the following features:

- Regulated 1.2-V output up to 20-A_{DC} steady-state output current
- The output voltage is marginable and trimmable using the PMBus interface
 - Programmable UVLO, soft-start, and enable via the PMBus interface
 - Programmable overcurrent warning and fault limits and programmable response to faults via the PMBus interface
 - Programmable overvoltage and undervoltage warning and fault limits and programmable response to faults via the PMBus interface
 - Programmable turn-on and turn-off delays
- Convenient test points for probing critical waveforms

2 Electrical Performance Specifications

Table 2-1 lists the electrical performance specifications in room temperature (20 to 25°C). Characteristics are given for an input voltage of $V_{IN} = 12\text{ V}$, unless otherwise specified.

Table 2-1. TPS546B24AEVM-1PH Electrical Performance Specifications

Parameter	Test Conditions	MIN	TYP	MAX	Unit
Input Characteristics					
Input voltage range, V _{IN}		5	12	18	V
Full load input current	I _{OUT} = 20 A		2.24		A
Full load input current	V _{IN} = 5 V, I _{OUT} = 20 A		5.3		A
No load input current	I _{OUT} = 0 A, switching enabled		65		mA
Enable switching threshold	Set by default resistor divider, JP4 pins 3 and 4 shorted		4.7		V
Disable switching threshold	Set by default resistor divider, JP4 pins 3 and 4 shorted		4.22		V
Output Characteristics					
Output voltage, V _{OUT}			1.2		V
Output load current, I _{OUT}		0		20	A
Output voltage regulation	Line Regulation: V _{IN} = 5 V to 18 V		0.1%		
	Load Regulation: I _{OUT} = 0 A to 20 A		0.1%		
Output voltage ripple	I _{OUT} = 20 A		8		mVpp
Output voltage undershoot	I _{OUT} = 5-A to 15-A step at 10 A/μs		40		mV
Output voltage overshoot	I _{OUT} = 15-A to 5-A step at 10 A/μs		40		mV
Output overcurrent fault threshold	Phase current limit setting programmed by MSEL2		26		A
Systems Characteristics					
Switching frequency	Programmed by MSEL1		650		kHz
Full load efficiency, V _{OUT} ⁽¹⁾	I _{OUT} = 20 A		89.5%		
Operating case temperature	I _{OUT} = 20 A, 10 minute soak		52.3		°C
Loop bandwidth	I _{OUT} = 20 A		37		kHz
Phase margin			75		°
PMBus Interface and Pin-Strapping					
PMBus address	Programmed by NVM and ADRSEL		36		Decimal
Voltage reference	Default setting of VOUT_COMMAND programmed by VSEL		1.2		V
Soft-start time (TON_RISE)	Default setting of TON_RISE programmed by MSEL2		3		ms

- (1) The efficiency is measured using the test points listed in [Table 6-1](#) to minimize the effect of DC drops caused by onboard copper traces.

3 Schematic

Figure 3-1 through Figure 3-2 illustrate the TPS546B24AEVM-1PH schematics.




Figure 3-1. TPS546B24AEVM-1PH Schematic - Main Circuit




Figure 3-2. TPS546B24AEVM-1PH Schematic - Connectors and Charge Pumps

4 Test Setup

4.1 Test and Configuration Software

To change any of the default configuration parameters on the EVM through PMBus, obtain the [TI Fusion Digital Power Designer](#) software.

4.1.1 Description

The *TI Fusion Digital Power Designer* is the graphical user interface (GUI) used to configure and monitor the Texas Instruments TPS546B24A power converter installed on this evaluation module. The application uses the PMBus protocol to communicate with the controller over serial bus by way of a TI USB adapter described in [Section 4.2.6](#).

4.1.2 Features

Some of the tasks you can perform with the GUI include:

- Turn on or off the power supply output, either through the hardware control line or the PMBus operation command.
- Monitor real-time data. Items such as input voltage, output voltage, output current, die temperature, and warnings and faults that are continuously monitored and displayed by the GUI.
- Configure common operating characteristics such as V_{OUT} trim and margin, UVLO, soft-start time, warning and fault thresholds, fault response, and On/Off modes.

4.2 Test Equipment

4.2.1 Voltage Source

The input voltage source V_{IN} should be a 0-V to 20-V variable DC source capable of supplying a minimum of 6 A_{DC} to support 20-A load with 5-V input. Connect input VIN and GND to T2 and T3. If the output voltage of the EVM is increased, the power supply may need to be capable of supplying more current.

4.2.2 Multimeters

TI recommends using two separate multimeters: one meter to measure V_{IN} and the other to measure V_{OUT} .

4.2.3 Output Load

A variable electronic load is recommended for the test setup. To test the full load current this EVM supports, the load should be capable of sinking at least 20 A.

4.2.4 Oscilloscope

When using an oscilloscope to measure the switching node voltage or voltage ripple, measure using a *Tip-and-Barrel* method as [Figure 4-1](#) shows, or better.

4.2.5 Fan

During prolonged operation at high loads, it may be necessary to provide forced air cooling with a small fan aimed at the EVM. Maintain the surface temperature of the devices on the EVM below their rated temperature.

4.2.6 USB-to-GPIO Interface Adapter

A communications adapter is required between the EVM and the host computer. This EVM is designed to use TI's USB-to-GPIO Adapter. Purchase this adapter at <http://www.ti.com/tool/usb-to-gpio>.

4.2.7 Recommended Wire Gauge

- Input VIN and GND to T2 and T3 (GND) (12-V input) – The recommended wire size is AWG #16 or better, with the total length of wire less than 2 feet (1 foot input, 1 foot return).
- Output T6 and GND T7 (1.2-V output) – The recommended wire size is AWG #14 or better, with the total length of wire less than 2 feet (1 foot output, 1 foot return). A thicker wire gauge may be required to minimize the voltage drop in the wires.

4.3 Tip and Barrel Measurement

Figure 4-1 illustrates the tip and barrel measurement for switching node waveform on TP14 with TP15.




Figure 4-1. Tip and Barrel Measurement

4.4 List of Test Points, Jumpers, and Connectors

Table 4-1 lists the test point functions.

Table 4-1. Test Point Functions

Test Point	Type	Name	Description
TP1	T-H Loop	EXT_AVIN	AVIN measurement point
TP2	T-H Loop	GND	GND reference
TP3	T-H Loop	CNTL	CNTL signal on J2 header
TP4	T-H Loop	DATA	DATA signal on J2 header
TP5	T-H Loop	CLK	CLK signal on J2 header
TP6	T-H Loop	SMBALRT	SMBALERT signal on J2 header
TP7	T-H Loop	MSEL2	MSEL2 measurement point for U1
TP8	T-H Loop	VSEL	VSEL measurement point for U1
TP9	T-H Loop	PG	PGOOD signal of U1
TP10	T-H Loop	VSHARE	VSHARE measurement point. Sensitive signal
TP11	T-H Loop	SYNC	External SYNC input
TP12	T-H Loop	PVIN	VIN+ measurement point
TP13	T-H Loop	VDD5	VDD5 measurement point or external VDD5 input
TP14	T-H Loop	SW	Switching node, reference to TP15
TP15	T-H Loop	GND	GND reference for switch node measurement
TP16	T-H Loop	CH_A	INPUT for small signal loop gain measurements (B/A setup)
TP17	T-H Loop	CH_B	OUTPUT for small signal loop gain measurements (B/A setup)
TP18	T-H Loop	GND	GND reference
TP19	T-H Loop	GND	VIN- measurement point
TP20	T-H Loop	GND	GND reference for U1 PVIN for efficiency measurement
TP21	T-H Loop	GND	GND reference for VOUT for efficiency measurement
TP22	T-H Loop	Remote SNS+	OUTPUT remote sense + voltage point
TP23	T-H Loop	PVIN_EFF	PVIN pin voltage of U1 measurement point for efficiency, reference to TP20
TP24	T-H Loop	VOUT_EFF	VOUT measurement point for efficiency, reference to TP21
TP25	T-H Loop	Remote SNS-	OUTPUT remote sense - voltage point
TP26	T-H Loop	GND	VOUT - measurement point
TP27	T-H Loop	VOUT	VOUT + measurement point
TP28	T-H Loop	VOUT_FILT	VOUT_FILT measurement point when using second stage filter

Table 4-2 lists the EVM jumpers.

Table 4-2. Jumpers

Jumper	Type	Name	Description
JP1	Header, 100 mil, 2 × 1	Micro_USB-PVIN	Short to connect PVIN to Micro USB connector
JP2	Header, 100 mil, 2 × 1	PMBus3.3V-AVIN	Short to connect USB-to-GPIO 3.3V to AVIN
JP3	Header, 100 mil, 3 × 1	AVIN Select	AVIN input source selections
JP4	Header, 100 mil, 3 × 2	EN Select	EN/UVLO pin selections

Table 4-3 lists the options for the EN/UVLO pin selection.

Table 4-3. JP4 Selections

Shunt Position	Selection
pin 1 to 2 shorted	PMBus adapter control signal
pin 3 to 4 shorted	Resistor divider to PVIN
pin 5 to 6 shorted	EN/UVLO short to ground

Table 4-4 lists the options for the AVIN selection.

Table 4-4. JP3 Selections

Shunt Position	Selection
pin 1 to 2 shorted	AVIN pin connected to AVIN input through 10-Ω resistor. Use this selection when testing with a split rail input.
pin 2 to 3 shorted	AVIN pin connected to PVIN through 10-Ω resistor

Table 4-5 lists the EVM connector functions.

Table 4-5. Connector Functions

Connector	Type	Name	Description
J1	Micro USB	Micro USB	Micro USB connector to power EVM from a 5 V USB source
J2	Header, 100 mil, 5 × 2	PMBus connector	PMBus socket for TI FUSION adapter
T1	Terminal block, 2 × 1	Ext_AVIN	External AVIN connector
T2	Terminal block, 2 × 1	PVIN	VIN+ connector
T3	Terminal block, 2 × 1	GND	VIN– connector
T4	Terminal block, 2 × 1	GND	VOUT_FILT– connector
T5	Terminal block, 2 × 1	VOUT_FILT	VOUT_FILT+ connector
T6	Terminal block, 2 × 1	VOUT	VOUT+ connector
T7	Terminal block, 2 × 1	GND	VOUT– connector

4.5 Evaluating Split Rail Input

The default configuration of the EVM is for single rail input. Split rail input enables operation with 3.3V PVIN. For split rail operation, configure the jumpers on the EVM as follows:

1. Move the jumper JP3 to position 1-2 to disconnect the AVIN pin from the PVIN pin.
2. Apply the AVIN input to T1. 4-V or greater AVIN is required to bring the VDD5 voltage high enough to enable conversion.
3. If operation with 3.3-V PVIN is needed and the EN Select jumper (JP4) is in position 3-4, the resistor divider at the EN/UVLO will need to be changed. Alternately move the EN Select jumper to position 1-2 and use the control signal to enable conversion or use the *On/Off Config* and *OPERATION* commands to enable conversion.

4.6 Configuring EVM to Overdrive VDD5

The EVM has a testpoint TP13 that can be used to overdrive VDD5. Externally applying VDD5 is useful to minimize the power dissipation in the TPS546B24A IC when using a single rail input by moving the loss from the internal LDO of the TPS546B24A to the external supply connected to TP13.

To overdrive the internal LDO, ensure the VDD5 output of the TPS546B24A is set below the external supply voltage connected from TP13 to ground (for example, TP2).

4.7 Powering from a Single 3.3-V Input Power Supply

The EVM includes two charge pump options to enable powering the TPS546B24A from a single 3.3-V input supply. The operation of these charge pumps is discussed in the [Powering the TPS546B24A Device Family from a Single 3.3-V Input Power Supply Application Report](#).

Before implementing the following instructions to use one of the charge pump circuits, it is first necessary to modify the conditions that enable power conversion. By default, the EVM is configured to start switching when PVIN goes above 4.7 V based on the R1 and R2 voltage divider to the EN pin. Increasing R2 from 8.66 k Ω to 16.2 k Ω sets the enable threshold to approximately 3.0 V. An alternative method is to use the Fusion GUI to change the *On/Off Config* setting to *Always Converting* such that the device is enabled whenever power is present, regardless of the state of the EN pin or the *OPERATION* command. The configuration screen is shown in [Figure 10-3](#). Be sure to *Store Config to NVM* after writing the change to hardware such that the setting persists after power is removed and reapplied.

To use the discrete charge pump, modify the EVM as follows:

1. Modify the enable threshold or *On/Off Config* of the device as described previously.
2. Set SYNC pin as an output. This can be accomplished by doing *either* of the following:
 - a. Populate ADRSEL pin-strap resistor divider with R9 = 2.05 k Ω and R10 = 10 k Ω .
 - b. Use Fusion GUI to set the *SYNC_DIR* bits of the *SYNC_CONFIG* register to *01b: Enable SYNC OUT*. This register can be set from the *All Config* tab in Fusion GUI, shown in [Figure 10-8](#). Be sure to *Store Config to NVM* after writing the change to hardware.
3. Remove the jumper JP3 to disconnect AVIN from both the external AVIN header (T1) and from PVIN.
4. Populate the resistors R26, R27, and R29 with 0- Ω resistors.
5. Apply PVIN input voltage. Note that the output voltage of the discrete charge pump will be approximately 2 \times PVIN (minus two diode drops). Pay careful attention that the applied PVIN remains below 9 V such that the generated AVIN does not exceed the 18-V rating of the converter IC.

To use the charge pump IC TPS60150, modify the EVM as follows:

1. Modify the enable threshold or *On/Off Config* of the device as described previously.
2. Remove the jumper JP3 to disconnect AVIN from both the external AVIN header (T1) and from PVIN.
3. Populate the resistors R30 and R31 with 0- Ω resistors.
4. Apply PVIN input voltage. Pay careful attention that the applied PVIN remains below the 5.5-V input rating of the TPS60150 charge pump IC.

Note

Only one charge pump circuit should be connected and used at a time. Remove the 0- Ω resistors that connect the charge pump to PVIN and AVIN (and SYNC for the discrete charge pump) before connecting the other charge pump, or before testing other conditions with higher input voltages that do not require the charge pump.

5 EVM Configuration Using the Fusion GUI

The TPS546B24A IC leaves the factory pre-configured. The factory default settings for the parameters can be found in the data sheet. If configuring the EVM to settings other than the factory defaults, use the software described in [Section 4.1](#). It is necessary to have the input voltage applied to the EVM prior to launching the software so that the TPS546B24A may respond to the GUI and the GUI can recognize the device. The default configuration for the EVM to stop converting is set by the EN/UVLO resistor divider to a nominal input voltage of 4.22 V; therefore, an input voltage less than 4.22 V should be applied to avoid any converter activity during configuration. TI recommends an input voltage of 3.3 V.

5.1 Configuration Procedure

1. Adjust the input supply to provide 3.3 VDC, current limited to 1 A.
2. Apply the input voltage to the EVM. See [Section 4.2](#) for connections and test setup.
3. Launch the Fusion GUI software. See the screen shots in [Section 10](#) for more information.
4. Configure the EVM operating parameters as desired.

6 Test Procedure

6.1 Line and Load Regulation and Efficiency Measurement Procedure

1. Set up the EVM as [Section 4.2](#) and [Section 6.2](#) describe.
2. Set the electronic load to draw 0 A_{DC}.
3. Increase V_{IN} from 0 V to 12 V using voltage meter to measure input voltage.
4. Use the other voltage meter to measure output voltage V_{OUT}.
5. Vary the load from 0 to 20 A_{DC}. V_{OUT} should remain in regulation as defined in [Table 2-1](#).
6. Vary V_{IN} from 5 V to 18 V. V_{OUT} should remain in regulation as defined in [Table 2-1](#).
7. Decrease the load to 0 A.
8. Decrease V_{IN} to 0 V.

6.2 Efficiency Measurement Test Points

To evaluate the efficiency of the power train (device and inductor), it is important to measure the voltages at the correct location. This is necessary because otherwise the measurements will include losses that are not related to the power train itself. Losses incurred by the voltage drop in the copper traces and in the input and output connectors are not related to the efficiency of the power train, which should not be included in efficiency measurements.

Input current can be measured at any point in the input wires, and output current can be measured anywhere in the output wires of the output being measured.

[Table 6-1](#) shows the measurement points for input voltage and output voltage. VIN and VOUT are measured to calculate the efficiency. Using these measurement points will result in efficiency measurements that excludes losses due to the wires and connectors as well as PCB voltage drops.

Table 6-1. Test Points for Efficiency Measurements

Test Point	Node Name	Description	Comment
TP23	PVIN	Input voltage measurement point for VIN+	This pair of test points are connected to PVIN and PGND near the pins of U1. The voltage drop between input terminal to the device pins is not included for efficiency measurement.
TP20	PGND	Input voltage measurement point for VIN- (GND)	
TP24	VOUT_EFF	Output voltage measurement point for VOUT+	This pair of test points are connected to VOUT and GND near the output inductor. The voltage drop from the output point of the inductor to the output terminals is not included for efficiency measurement.
TP21	GND	Output voltage measurement point for VOUT- (GND)	

6.3 Control Loop Gain and Phase Measurement Procedure

The TPS546B24AEVM-1PH includes a 100.0-Ω series resistor in the feedback loop for V_{OUT}. The resistor is accessible at the test points TP16 and TP17 for loop response analysis. These test points should be used during loop response measurements as the perturbation injecting points for the loop . See the description in [Table 6-2](#).

Table 6-2. List of Test Points for Loop Response Measurements

Test Point	Node Name	Description	Comment
TP16	CH_A	Input to feedback divider of V _{OUT}	The amplitude of the perturbation at this node should be limited to less than 30 mV
TP17	CH_B	Resulting output of V _{OUT}	Bode can be measured by a network analyzer with a CH_B/CH_A configuration

Measure the loop response with the following procedure:

1. Set up the EVM as described in [Section 4.2](#).
2. For V_{OUT}, connect the isolation transformer of the network analyzer from TP16 to TP17.
3. Connect the input signal measurement probe to TP16. Connect the output signal measurement probe to TP17.
4. Connect the ground leads of both probe channels to TP18.
5. On the network analyzer, measure the Bode as TP17/TP16 (Out/In).

7 Performance Data and Typical Characteristic Curves

Figure 7-1 through Figure 7-3 present typical performance curves for the TPS546B24AEVM-1PH. The input voltage is 12 V and the oscilloscope measurements use 20 MHz bandwidth limiting unless otherwise noted.

7.1 Efficiency




Figure 7-1. Efficiency

7.2 Load and Line Regulation (Measured Between TP27 and TP26)




Figure 7-2. Load Regulation




Figure 7-3. Line Regulation

7.3 Transient Response

Figure 7-4 shows the transient response waveform with a 5 A to 15 A transient at 10 A/ μ s




Figure 7-4. Transient Response

7.4 Control Loop Bode Plot

Figure 7-5 is the control loop bode plot.




Figure 7-5. Bode Plot at 1.2-V Output at 12 V_{IN}, 20-A Load

7.5 Output Ripple

Figure 7-6 and Figure 7-7 show the output ripple waveforms at 0-A and 40-A load.




Figure 7-6. Output Ripple With 0-A Load




Figure 7-7. Output Ripple With 20-A Load

7.6 Power MOSFET Drain-Source Voltage

Figure 7-8 and Figure 7-9 show the low-side and high-side MOSFET drain-source voltage (V_{DS}) at 20-A load. The voltage is measured with 1-GHz bandwidth and at the solder mask openings near the U1 IC using a 1-GHz differential probe.




Figure 7-8. Low-side MOSFET V_{DS}




Figure 7-9. High-side MOSFET V_{DS}

7.7 Control On

Figure 7-10 illustrates the start-up from control on waveforms at 20-A output.




Figure 7-10. Start-Up From Control, 20-A CC Load

7.8 Control Off

Figure 7-11 illustrates the control off waveforms at 20-A output.




Figure 7-11. Shutdown From Control, 20-A CC Load

7.9 Control On With Pre-biased Output

Figure 7-12 illustrates the control on waveforms with a pre-biased output voltage.





Figure 7-12. Start-Up From Control With Pre-biased Output

7.10 Thermal Image

Figure 7-13 shows the TPS546B24AEVM-1PH thermal image.



$V_{IN} = 12\text{ V}$, $I_{OUT} = 20\text{ A}$

Figure 7-13. Thermal Image

8 EVM Assembly Drawing and PCB Layout

Figure 8-1 through Figure 8-12 show the design of the TPS546B24AEVM-1PH printed circuit board.




Figure 8-1. TPS546B24AEVM-1PH 3D Top View




Figure 8-2. TPS546B24AEVM-1PH 3D Bottom View




Figure 8-3. TPS546B24AEVM-1PH Top Side Component View (Top View)




Figure 8-4. TPS546B24AEVM-1PH Bottom Side Component View (Bottom View)




Figure 8-5. TPS546B24AEVM-1PH Top Copper (Top View)




Figure 8-6. TPS546B24AEVM-1PH Internal Layer 1 (Top View)




Figure 8-7. TPS546B24AEVM-1PH Internal Layer 2 (Top View)




Figure 8-8. TPS546B24AEVM-1PH Internal Layer 3 (Top View)




Figure 8-9. TPS546B24AEVM-1PH Internal Layer 4 (Top View)




Figure 8-10. TPS546B24AEVM-1PH Internal Layer 5 (Top View)




Figure 8-11. TPS546B24AEVM-1PH Internal Layer 6 (Top View)




Figure 8-12. TPS546B24AEVM-1PH Internal Bottom Layer (Top View)

9 Bill of Materials

Table 9-1 lists the BOM for the TPS546B24AEVM-1PH.

Table 9-1. Bill of Materials

Designator	Quantity	Value	Description	PackageReference	PartNumber	Manufacturer
!PCB1	1		Printed Circuit Board		BSR132	Any
C1, C17	2	330uF	CAP, Tantalum Polymer, 330 uF, 10 V, +/- 20%, 0.006 ohm, 7343-43 SMD	7343-43	T530X337M010ATE006	Kemet
C2, C3, C4, C18, C19, C20	6	100uF	CAP, CERM, 100 µF, 6.3 V, +/- 20%, X7S, 1210	1210	GRM32EC70J107ME15L	MuRata
C9	1	100uF	CAP, AL, 100 uF, 35 V, +/- 20%, 0.15 ohm, SMD	SMT Radial G	EEE-FC1V101P	Panasonic
C10, C11, C24, C25	4	22uF	CAP, CERM, 22 uF, 25 V, +/- 10%, X6S, 1210	1210	GRM32EC81E226KE15L	MuRata
C12, C13, C26	3	6800pF	CAP, CERM, 6800 pF, 50 V, +/- 10%, X7R, 0402	0402	GCM155R71H682KA55D	MuRata
C14	1	1uF	CAP, CERM, 1 uF, 25 V, +/- 10%, X7R, 0603	0603	C0603C105K3RACTU	Kemet
C15	1	0.1uF	CAP, CERM, 0.1 uF, 50 V, +/- 10%, X7R, 0603	0603	C0603C104K5RACTU	Kemet
C16	1	1000pF	CAP, CERM, 1000 pF, 100 V, +/- 5%, X7R, 0603	0603	06031C102JAT2A	AVX
C27	1	4.7uF	CAP, CERM, 4.7 uF, 10 V, +/- 10%, X5R, 0603	0603	C0603C475K8PACTU	Kemet
C29	1	100pF	CAP, CERM, 100 pF, 50 V, +/- 5%, C0G/NP0, 0603	0603	C1608C0G1H101J080AE	TDK
C30	1	2.2uF	CAP, CERM, 2.2 uF, 16 V, +/- 10%, X7R, 0603	0603	EMK107BB7225KA-T	Taiyo Yuden
C32	1	0.1uF	CAP, CERM, 0.1 uF, 50 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0402	0402	CGA2B3X7R1H104K050BB	TDK
C34, C35, C37, C39	4	2.2uF	CAP, CERM, 2.2 µF, 25 V, +/- 10%, X7S, 0603	0603	GRM188C71E225KE11D	MuRata
C36	1	0.22uF	CAP, CERM, 0.22 µF, 16 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0402	0402	GCM155R71C224KE02D	MuRata
C38	1	10uF	CAP, CERM, 10 µF, 25 V, +/- 20%, X6S, 0805	0805	GRM21BC81E106ME51L	MuRata
D1, D2	2	30V	Diode, Schottky, 30 V, 2 A, AEC-Q101, SOD-123FL	SOD-123FL	MBR230LSFT1G	ON Semiconductor
D3	1		DIODE ARRAY SCHOTTKY 40V SOT363	SOT363	SD103ATW-7-F	Diodes
H5, H6, H7, H8	4		Bump, Hemisphere, 0.375 X 0.235, Black	Black Bump	SJ61A2	3M
J1	1		Connector, Receptacle, Micro-USB Type B, R/A, Bottom Mount SMT	MICRO USB CONN, R/A	1981568-1	TE Connectivity
J2	1		Header (shrouded), 100mil, 5x2, Gold, TH	5x2 Shrouded header	5103308-1	TE Connectivity
JP3	1		Header, 100mil, 3x1, Gold, TH	PBC03SAAN	PBC03SAAN	Sullins Connector Solutions
JP4	1		Header, 100mil, 3x2, Gold, TH	Sullins 100mil, 2x3, 230 mil above insulator	PBC03DAAN	Sullins Connector Solutions
L1	1	300nH	Inductor, Shielded, Ferrite, 300 nH, 34 A, 0.000228 ohm, SMD	10.8x7.2x7.5mm	SLC1175-301MEB	Coilcraft
LBL1	1		Thermal Transfer Printable Labels, 0.650" W x 0.200" H - 10,000 per roll	PCB Label 0.650 x 0.200 inch	THT-14-423-10	Brady
LED1	1	Green	LED, Green, SMD	LED_0603	150060GS75000	Würth Elektronik
Q1	1	30V	MOSFET, 2-CH, N/P-CH, 30 V, 0.65 A, SOT-363	SOT-363	DMC3400SDW-7	Diodes Inc.
R1	1	30.1k	RES, 30.1 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW040230K1FKED	Vishay-Dale
R2	1	8.66k	RES, 8.66 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW04028K66FKED	Vishay-Dale
R3, R4	2	10	RES, 10, 5%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	CRCW060310R0JNEA	Vishay-Dale
R6, R13, R19	3	0	RES, 0, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW04020000Z0ED	Vishay-Dale
R8	1	68.1k	RES, 68.1 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW040268K1FKED	Vishay-Dale
R11	1	17.8k	RES, 17.8 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW040217K8FKED	Vishay-Dale
R12	1	26.1k	RES, 26.1 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW040226K1FKED	Vishay-Dale
R14	1	1.0	RES, 1.0, 5%, 0.25 W, AEC-Q200 Grade 0, 1206	1206	CRCW12061R00JNEA	Vishay-Dale

Table 9-1. Bill of Materials (continued)

Designator	Quantity	Value	Description	PackageReference	PartNumber	Manufacturer
R18, R23	2	49.9	RES, 49.9, 1%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	CRCW060349R9FKEA	Vishay-Dale
R20	1	10.0k	RES, 10.0 k, 1%, 0.063 W, 0402	0402	RC0402FR-0710KL	Yageo America
R21, R22	2	100	RES, 100, 1%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	CRCW0603100RFKEA	Vishay-Dale
R24, R25	2	10.0	RES, 10.0, 1%, 0.25 W, AEC-Q200 Grade 0, 0603	0603	CRCW060310R0FKEAHP	Vishay-Dale
R28	1	1.00k	RES, 1.00 k, 1%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	CRCW06031K00FKEA	Vishay-Dale
SH-JP3, SH-JP4	2	1x2	Shunt, 100mil, Gold plated, Black	Shunt	SNT-100-BK-G	Samtec
SMB1, SMB2	2		Connector, Receptacle, 50 ohm, TH	SMB Connector	SMBR004D00	JAE Electronics
T1	1		Terminal Block, 3.5mm Pitch, 2x1, TH	7.0x8.2x6.5mm	ED555/2DS	On-Shore Technology
T2, T3, T6, T7	4		Terminal Block, 5.08 mm, 2x1, Brass, TH	2x1 5.08 mm Terminal Block	ED120/2DS	On-Shore Technology
TP1, TP12, TP13, TP23, TP24, TP27	6		Test Point, Multipurpose, Red, TH	Red Multipurpose Testpoint	5010	Keystone
TP2, TP15, TP18, TP19, TP20, TP21, TP26	7		Test Point, Multipurpose, Black, TH	Black Multipurpose Testpoint	5011	Keystone
TP3, TP4, TP5, TP6, TP9, TP10, TP11, TP14, TP16, TP17, TP22, TP25	12		Test Point, Multipurpose, White, TH	White Multipurpose Testpoint	5012	Keystone
U1	1		2.95-16V 20A PMBUS Stackable Synchronous Buck Converter, RVF0040A (LQFN-CLIP-40)	RVF0040A	TPS546B24ARVFR	Texas Instruments
U2	1		5 V, Step-Up Charge Pump Regulator, 140 mA, 2.7 to 5.5 V Input, -40 to 85 degC, 6-pin SON (DRV6), Green (RoHS & no Sb/Br)	DRV0006A	TPS60150DRVFR	Texas Instruments
C5, C6, C7	0	100uF	CAP, CERM, 100 uF, 6.3 V, +/- 20%, X7S, 1210	1210	GRM32EC70J107ME15L	MuRata
C8	0	100uF	CAP, AL, 100 uF, 35 V, +/- 20%, 0.15 ohm, SMD	SMT Radial G	EEE-FC1V101P	Panasonic
C21, C22, C23	0	47uF	CAP, CERM, 47 uF, 10 V, +/- 10%, X7R, 1210	1210	GRM32ER71A476KE15L	MuRata
C28	0	0.1uF	CAP, CERM, 0.1 uF, 50 V, +/- 10%, X7R, 0603	0603	C0603C104K5RACTU	Kemet
C31, C33	0	33pF	CAP, CERM, 33 pF, 50 V, +/- 5%, C0G/NP0, 0603	0603	C0603C330J5GACTU	Kemet
FID1, FID2, FID3	0		Fiducial mark. There is nothing to buy or mount.	N/A	N/A	N/A
JP1, JP2	0		Header, 100mil, 2x1, Tin, TH	Header, 2x1, 100mil, TH	5-146278-2	TE Connectivity
R5, R7, R9, R10	0	10.5k	RES, 10.5 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	CRCW040210K5FKED	Vishay-Dale
R15, R16	0	100	RES, 100, 1%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	CRCW0603100RFKEA	Vishay-Dale
R17	0	49.9	RES, 49.9, 1%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	CRCW060349R9FKEA	Vishay-Dale
R26, R27, R29, R30, R31	0	0	RES, 0, 5%, 0.1 W, 0603	0603	RC0603JR-070RL	Yageo
SH-JP1, SH-JP2	0	1x2	Shunt, 100mil, Gold plated, Black	Shunt	SNT-100-BK-G	Samtec
SMB3	0		Connector, Receptacle, 50 ohm, TH	SMB Connector	SMBR004D00	JAE Electronics
T4, T5	0		Terminal Block, 5.08 mm, 2x1, Brass, TH	2x1 5.08 mm Terminal Block	ED120/2DS	On-Shore Technology
TP7, TP8	0		Test Point, Miniature, Red, TH	Red Miniature Testpoint	5000	Keystone
TP28	0		Test Point, Multipurpose, Red, TH	Red Multipurpose Testpoint	5010	Keystone

10 Using the Fusion GUI

10.1 Opening the Fusion GUI

The Fusion GUI should include `IC_DEVICE_ID` in the scanning mode to find TPS546B24A. The EVM needs power to be recognized by the Fusion GUI. See [Section 5](#) for the recommended procedure.




Figure 10-1. Select Device Scanning Mode

10.2 General Settings

Figure 10-2 shows the *General Settings* that can be used to configure the following:

- Vout settings, power good limits and margin voltages
- OC Fault, OC Warn and Fault response
- OT Fault, OT Warn (Die Temperature) and Fault response
- Vin on and off UVLO
- On/Off Config
- Soft Start (Output rise time), other Turn On Timing and Turn Off Timing
- Switching frequency
- Compensation

After clicking *Write to Hardware* to make changes to one or more configurable parameters, the changes can be committed to nonvolatile memory by clicking *Store Config to NVM*. This action prompts a pop-up, and if confirmed, the changes are committed to nonvolatile memory to store all the modifications in non-volatile memory.

Both the loop master device and the loop slave device are tied to same bus interface. In a two-phase stacking system, the master device will receive and respond to all PMBus communication and slave devices do not need to be connected to the PMBus. If the master receives commands which require updates to the PMBus registers of the slave, the master will relay these commands to the slaves. All commands on this tab are for PHASE = 0xFF.




Figure 10-2. General Settings

10.3 Changing ON_OFF_CONFIG

Changing the *On/Off Config* prompts a pop-up window with details of the options shown in Figure 10-3. This pop-up gives multiple options on what turns on and off power conversion. By default the TPS546B24A is configured to *CONTROL Pin Only*. This is the EN/UVLO pin.




Figure 10-3. Configure – ON_OFF_CONFIG

10.4 Pop-up for Some Commands While Conversion is Enabled

Some commands will cause a pop-up like the one shown in [Figure 10-4](#) when trying to change them while conversion is enabled. The settings in the GUI which will cause this pop-up include *FREQUENCY_SWITCH*, *USER_DATA_01 (Compensation)*, *Vout Mode* and *Vout Scale Loop*. To change these settings to a new value, click on *Stop Power Conversion* then *Close and continue*. The GUI will automatically disable conversion, write the new value, and enable conversion again.




Figure 10-4. Pop-up When Trying to Change FREQUENCY_SWITCH With Conversion Enabled

10.5 SMBALERT# Mask

The sources of SMBALERT which can be masked are found and configured on the *SMBALERT # Mask* tab (Figure 10-5).




Figure 10-5. Configure – SMBALERT # Mask

10.6 Device Info

The device information, Write Protection options, the configuration of *Vout Scale Loop*, *Vout Transition Rate*, and *Iout Cal Offset* are found on the *Device Info* tab (see [Figure 10-6](#)).




Figure 10-6. Configure – Device Info

10.7 Phase Commands

Use the *Phase Command* tab (see [Figure 10-7](#)) to calibrate the *IOUT/Temp* of each phase.





Figure 10-7. Phase Commands

10.8 All Config

Use the *All Config* tab (Figure 10-8) to configure all of the configurable parameters, which also shows other details like Hex encoding.



Configuration TPS546D24A @ PMBus Addr 36d (24h) / I2C Addr 72d (48h)

File Device Tools

Write to Hardware Discard Changes Store Config to NVM Restore NVM Config Error Checking

Configure General Setting SMBALERT# Mask Device Info Phase Commands Pin Strapping **All Config**

Sort Parameters By:
☒ Command Name
☐ Command Code
☒ Group by Category

Command	Code	Value/Edit	Hex/Edit
Calibration			
IOUT_CAL_GAIN phase ALL	0x38	1.000	0xC880
IOUT_CAL_OFFSET phase ALL	0x39	0.0000 A	0xE000
VOUT_SCALE_LOOP	0x29	0.500	0xC840
VOUT_TRIM	0x22	0.000000 V	0x0000
Configuration			
FREQUENCY_SWITCH	0x33	550 kHz	0x0226
IC_DEVICE_ID	0xAD	0x54495...	0x54...
IC_DEVICE_REV	0xAE	0x4000	0x4000
INTERLEAVE	0x37	Group ID...	0x0020
MISC_OPTIONS [MFR 29]	0xED	PEC: Fals...	0x0000
PGOOD_CONFIG [MFR 19]	0xE3	PGood O...	0x009F
PIN_DETECT_OVERRIDE [MFR 30]	0xEE	Stack Co...	0x1F2F
SMBALERT_MASK_CML	0x1B	00000000	0x00
SMBALERT_MASK_INPUT	0x1B	11101000	0xE8
SMBALERT_MASK_IOUT	0x1B	00011000	0x18
SMBALERT_MASK_MFR_SPECIFIC	0x1B	01000010	0x42
SMBALERT_MASK_OTHER	0x1B	00000001	0x01
SMBALERT_MASK_TEMPERATURE	0x1B	00000000	0x00
SMBALERT_MASK_VOUT	0x1B	00000010	0x02
STACK_CONFIG [MFR 28]	0xEC	Box Stop...	0x0001
SYNC_CONFIG [MFR 20]	0xE4	SYNC_Di...	0xF0
Manufacturer Info			
CAPABILITY	0x19	0x00	0xD0
MFR_MODEL	0x9A		0x00...
MFR_REVISION	0x9B		0x00...
MFR_SERIAL	0x9E		0x00...
PMBUS_REVISION	0x98	0x33	0x33
On/Off Configuration			
ON_OFF_CONFIG phase ALL	0x02	0x17	0x17
OPERATION	0x01	0x04	0x04
TOFF_DELAY	0x64	0.0 ms	0xF800
TOFF_FALL	0x65	0.50 ms	0xF002
TON_DELAY	0x60	0.0 ms	0xF800
TON_MAX_FAULT_LIMIT	0x62	0 ms	0xF800
TON_MAX_FAULT_RESPONSE	0x63	Click...	0x38
TON_RISE	0x61	3.00 ms	0xF00C
Status			
NVM_CHECKSUM [MFR 32]	0xF0	Checksu...	0xE9E0
READ_IOUT phase ALL	0x8C	-0.52 A	0xB5F0
READ_TEMPERATURE_1 phase ALL	0x8D	23 °C	0x0017
READ_VIN phase ALL	0x88	3.301 V	0xC34D
READ_VOUT phase ALL	0x8B	0.009786 V	0x0005
STATUS_BYTE	0x78	01000000	0x40
STATUS_CML	0x7E	00000000	0x00

Configure Monitor Status

PMBus Log

Fusion Digital Power Designer v7.1.28.Beta TPS546D24A @ PMBus Address 36d (24h) * Not Saved

Figure 10-8. Configure – All Config

10.9 Pin Strapping

Use the *Pin Strapping* tab (Figure 10-8) to aid in selection of external pin strapping resistors used to program some of the PMBus commands at power-up. The *EEPROM Value* column shows the values currently configured to the related PMBus commands.

Pin	PMBus Command	Pinstrap Setting	R_Divider		R_Bot		EEPROM Value	*
			Code	kΩ	Code	kΩ		
MSEL1	COMPENSATION CONFIG	ILOOP gain mb = EEPROM; VLOOP gain mb = EEPROM...	Open	DNP	Open	DNP	ILOOP mb = 4, VLOOP mb = 2	
	FREQUENCY SWITCH	275 kHz					550.000 kHz	
	OC_FAULT/OC_WARN	OCF = 52, OCV = 40 A					104 / 80 A	
MSEL2	TON_RISE	0.50 ms	0	21.500 kΩ	0	4.640 kΩ	3 ms	
	Num Slaves sharing VOUT	None, Stand alone					1 slave	
VSEL	Voltage Range	EEPROM					0.5 to 1.5 V	
	VOUT COMMAND	EEPROM	Open	DNP	Short	0.000 Ω	0.798628125 V	

Figure 10-9. Configure – Pin Strapping

10.10 Monitor

When the *Monitor* screen (Figure 10-10) is selected, the screen changes to display real-time data of the parameters that are measured by the device. This screen provides access to:

- Graphs of *Vout*, *Iout*, *Vin*, *Pout*, and *Temperature*
- *Start and Stop Polling* which turns ON or OFF the realtime display of data
- Quick access to *On/Off Config*
- Control pin activation and *OPERATION* command
- Margin control
- Clear Fault: Selecting **Clear Faults** clears any prior fault flags.

With two devices stacked together, the *Iout* reading is the total load supported by both devices. There is also an *Iout* which shows the current in each phase.




Figure 10-10. Monitor Screen

10.11 Status

Selecting *Status* screen from lower left corner (Figure 10-11) shows the status of the device.

The screenshot shows the 'Status' screen of the Fusion GUI for a TPS546D24A @ PMBus Addr 36d (24h) / 12C Addr 72d (48h). The interface includes a menu on the left with 'Status' selected, and a main area displaying various status registers. A central 'STATUS_WORD' register provides a summary of the overall device status.

Status Registers

- STATUS_VOUT**
 - 7 Vout OV Fault
 - 6 Vout OV Warning
 - 5 Vout UV Warning
 - 4 Vout UV Fault
 - 3 MAX/MIN Warn
 - 2 TON_MAX Fault
 - 1 Not supported
 - 0 Not supported
- STATUS_IOUT**
 - 7 IOUT OC Fault
 - 6 Not supported
 - 5 IOUT OC Warning
 - 4 Not supported
 - 3 Not supported
 - 2 Not supported
 - 1 Not supported
 - 0 Not supported
- STATUS_TEMP**
 - 7 OT Fault
 - 6 OT Warning
 - 5 UT Fault
 - 4 UT Warning
 - 3 Reserved
 - 2 Reserved
 - 1 Reserved
 - 0 Reserved
- STATUS_CML**
 - 7 Invalid Command
 - 6 Invalid Data
 - 5 PEC Fault
 - 4 Memory Fault
 - 3 Processor Fault
 - 2 Reserved
 - 1 Other Comms Fault
 - 0 Other Memory/Logic Fault
- STATUS_WORD**
 - 15 VOUT
 - 14 IOUT / POUT
 - 13 INPUT
 - 12 MFR
 - 11 POWER_GOOD#
 - 10 FANS
 - 9 OTHER
 - 8 Unknown
 - 7 Busy
 - 6 Output Off
 - 5 Vout OV Fault
 - 4 IOUT OC Fault
 - 3 Vin UV Fault
 - 2 TEMPERATURE
 - 1 CML
 - 0 More faults in high byte
- STATUS_INPUT**
 - 7 Vin OVF
 - 6 Not supported
 - 5 Vin UVW
 - 4 Not supported
 - 3 Unit off: Insufficient Vin
 - 2 Not supported
 - 1 Not supported
 - 0 Not supported
- STATUS_MFR_SPECIFIC**
 - 7 POR
 - 6 SELF_CHECK
 - 5 Reserved
 - 4 Reserved
 - 3 RESET
 - 2 BCX
 - 1 SYNC
 - 0 Reserved
- STATUS_OTHER**
 - 7 Not supported
 - 6 Not supported
 - 5 Not supported
 - 4 Not supported
 - 3 Not supported
 - 2 Not supported
 - 1 Not supported
 - 0 1st to ALERT
- STATUS IOUT Phase 0**
 - 7 IOUT OC Fault
 - 6 Not supported
 - 5 IOUT OC Warning
 - 4 Not supported
 - 3 Not supported
 - 2 Not supported
 - 1 Not supported
 - 0 Not supported
- STATUS IOUT Phase 1**
 - 7 IOUT OC Fault
 - 6 Not supported
 - 5 IOUT OC Warning
 - 4 Not supported
 - 3 Not supported
 - 2 Not supported
 - 1 Not supported
 - 0 Not supported
- STATUS INPUT Phase 0**
 - 7 Vin OVF
 - 6 Not supported
 - 5 Vin UVW
 - 4 Not supported
 - 3 Unit off: Insufficient Vin
 - 2 Not supported
 - 1 Not supported
 - 0 Not supported
- STATUS INPUT Phase 1**
 - 7 Vin OVF
 - 6 Not supported
 - 5 Vin UVW
 - 4 Not supported
 - 3 Unit off: Insufficient Vin
 - 2 Not supported
 - 1 Not supported
 - 0 Not supported
- STATUS TEMP Phase 0**
 - 7 OT Fault
 - 6 OT Warning
 - 5 UT Fault
 - 4 UT Warning
 - 3 Reserved
 - 2 Reserved
 - 1 Reserved
 - 0 Reserved
- STATUS TEMP Phase 1**
 - 7 OT Fault
 - 6 OT Warning
 - 5 UT Fault
 - 4 UT Warning
 - 3 Reserved
 - 2 Reserved
 - 1 Reserved
 - 0 Reserved
- STATUS CML Phase 0**
 - 7 Invalid Command
 - 6 Invalid Data
 - 5 PEC Fault
 - 4 Memory Fault
 - 3 Processor Fault
 - 2 Reserved
 - 1 Other Comms Fault
 - 0 Other Memory/Logic Fault
- STATUS CML Phase 1**
 - 7 Invalid Command
 - 6 Invalid Data
 - 5 PEC Fault
 - 4 Memory Fault
 - 3 Processor Fault
 - 2 Reserved
 - 1 Other Comms Fault
 - 0 Other Memory/Logic Fault

The bottom of the screen shows a 'PMBus Log' section and a status bar indicating 'Fusion Digital Power Designer v7.1.28 Beta | TPS546D24A @ PMBus Address 36d (24h) | * Not Saved'.

Figure 10-11. Status Screen

STANDARD TERMS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, and/or documentation which may be provided together or separately (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms set forth herein. User's acceptance of the EVM is expressly subject to the following terms.
 - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms that accompany such Software
 - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
 - 2.1 These terms do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
 - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for a nonconforming EVM if (a) the nonconformity was caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI, (b) the nonconformity resulted from User's design, specifications or instructions for such EVMs or improper system design, or (c) User has not paid on time. Testing and other quality control techniques are used to the extent TI deems necessary. TI does not test all parameters of each EVM. User's claims against TI under this Section 2 are void if User fails to notify TI of any apparent defects in the EVMs within ten (10) business days after delivery, or of any hidden defects with ten (10) business days after the defect has been detected.
 - 2.3 TI's sole liability shall be at its option to repair or replace EVMs that fail to conform to the warranty set forth above, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.

WARNING

Evaluation Kits are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems.

User shall operate the Evaluation Kit within TI's recommended guidelines and any applicable legal or environmental requirements as well as reasonable and customary safeguards. Failure to set up and/or operate the Evaluation Kit within TI's recommended guidelines may result in personal injury or death or property damage. Proper set up entails following TI's instructions for electrical ratings of interface circuits such as input, output and electrical loads.

NOTE:

EXPOSURE TO ELECTROSTATIC DISCHARGE (ESD) MAY CAUSE DEGRADATION OR FAILURE OF THE EVALUATION KIT; TI RECOMMENDS STORAGE OF THE EVALUATION KIT IN A PROTECTIVE ESD BAG.

3 Regulatory Notices:

3.1 United States

3.1.1 Notice applicable to EVMs not FCC-Approved:

FCC NOTICE: This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.

3.1.2 For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- *Reorient or relocate the receiving antenna.*
- *Increase the separation between the equipment and receiver.*
- *Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- *Consult the dealer or an experienced radio/TV technician for help.*

3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210 or RSS-247

Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see http://www.tij.co.jp/lscs/ti_ja/general/eStore/notice_01.page 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。
http://www.tij.co.jp/lscs/ti_ja/general/eStore/notice_01.page

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required to follow the instructions set forth by Radio Law of Japan, which includes, but is not limited to, the instructions below with respect to EVMs (which for the avoidance of doubt are stated strictly for convenience and should be verified by User):

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】 開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないもののご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。 日本テキサス・インスツルメンツ株式会社
東京都新宿区西新宿 6 丁目 2 4 番 1 号
西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see http://www.tij.co.jp/lscs/ti_ja/general/eStore/notice_02.page
電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。 http://www.tij.co.jp/lscs/ti_ja/general/eStore/notice_02.page

3.4 European Union

3.4.1 *For EVMs subject to EU Directive 2014/30/EU (Electromagnetic Compatibility Directive):*

This is a class A product intended for use in environments other than domestic environments that are connected to a low-voltage power-supply network that supplies buildings used for domestic purposes. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*

6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY MATERIALS PROVIDED WITH THE EVM (INCLUDING, BUT NOT LIMITED TO, REFERENCE DESIGNS AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY EPIDEMIC FAILURE WARRANTY OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.

6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT, REGARDLESS OF WHEN MADE, CONCEIVED OR ACQUIRED.

7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.

8. *Limitations on Damages and Liability:*

8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS OR THE USE OF THE EVMS, REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN TWELVE (12) MONTHS AFTER THE EVENT THAT GAVE RISE TO THE CAUSE OF ACTION HAS OCCURRED.

8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY USE OF AN EVM PROVIDED HEREUNDER, INCLUDING FROM ANY WARRANTY, INDEMNITY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS, EXCEED THE TOTAL AMOUNT PAID TO TI BY USER FOR THE PARTICULAR EVM(S) AT ISSUE DURING THE PRIOR TWELVE (12) MONTHS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.

10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2019, Texas Instruments Incorporated

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale (www.ti.com/legal/termsofsale.html) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2020, Texas Instruments Incorporated