

---

## Configure Regional Hub-and-Controller Nodes for SHHS Topologies

 For supported software information, click [here](#).

In addition to creating templates for hubs and spokes using workflow templates and spoke groups, you can configure hub-and-spoke topologies in a region. In a region, the communication between spoke devices that belong to different regions flows through the hubs in each region. Spokes in the same region can communicate with each other either through region-specific hubs or directly by specifying the topology using spoke groups. This topology is called a spoke-hub-hub-spoke (SHHS) topology.

For Releases 20.2.1 and later, you can create multiple spoke groups in a region.

This article provides an overview of the SHHS topology and describes how to configure it.

---

### SHHS Topology Overview


This section provides an overview of SHHS regions, having multiple spoke groups in a region, and hub-controller nodes.

---

#### Regions

You can group hubs and spokes together by configuring them to be in distinct regions. A region consists of hubs, spokes, and Controller nodes.

The following figure shows hubs and spokes deployed in two regions, Region-A and Region-B. In this figure, each region contains two hubs and two spokes. All four hubs connect to top-level Controller nodes, here, Controller-1 and Controller-2. The hubs are connected to each other in a full-mesh topology, and all hubs have established IPsec tunnels among them, indicated by the solid blue lines. All the hubs and spokes have established IKE-based IPsec tunnels with the two Controller nodes, indicated by the dotted red lines. The solid green lines in Region-A represent IPsec tunnels between the spokes and hubs. The solid green lines in Region-B represent IPsec tunnels between the spokes and hubs and between the two spokes.



To deploy hubs and spokes in different regions, you first create a region, as described in the [Create a Region](#) section, below.

The hubs and spokes that are deployed in a region tag the routes that they advertise with a special BGP community string, 8011:X, where X is the ID of the region. Spokes in a region accept only routes that contain the region's community string. Hubs in a region accept routes from other regions and re-advertise them to local spokes after adding the local region's community string.

When you configure a hub or a spoke group, you can choose to place them in a region. To have spokes in different regions to be part of the same spoke group, you must configure the region ID on each spoke.

If the entire enterprise network consists of only a single region, it is recommended that you use the region Global (Region ID 1) hub-controllers and spoke groups. Doing this ensures that hub-controllers readvertise the spokes' spoke-to-spoke direct Layer 3 VPN routes within the region.

The following screens show the newly added Region field in the workflow templates and in spoke groups.

**Edit Template - Multi\_Tenant\_PostStaging**

Basic | Interfaces | Routing | Tunnels | Inbound NAT | Services | Management Servers

Name\* Multi\_Tenant\_PostStaging Type\* SDWAN Post Staging Organization\* provider-org

Device Type SDWAN Region --Select--

Full Mesh ☒ Hub ☐ Hub Controller ☐ Spoke

Redundant Pair ☐ Enable ☐ VRRP ☐ Cloud CPE

Template Name

Sub Organizations: Tenant1, Tenant2, Tenant3, Tenant4

Controllers: SDWAN-Controller1, SDWAN-Controller2

Analytics Cluster: Analytics

+ Analytics Cluster Preferred Software Version: --Select--

Subscription: Solution Tier advanced-sdwan, Service Bandwidth 1 Gbps, Aggregate Bandwidth 1 Gbps

Solution Addon Tier

Custom Parameters: No Records to Display

☒ Primary ☒ Analytics Enabled

Cancel Continue Recreate

Monitor | Configuration | Workflows | Administration | Analytics

Infrastructure | Template | Application Steering | Spoke Groups | Service Chains | Devices

Name\* West-Spoke-Group-1 Organization\* Tenant1 Region --Please Select--

Hub ☒ Hub Controller ☐

Routing Instances	Spoke Group Type	Community	Hubs	Priority
Tenant1-LAN-VR	Spoke to Hub Only	--Please Select--	No Row Added	

+Community Options

Save Cancel


## Multiple Spoke Groups in a Region

*For Releases 20.2.1 and later.*

You can create multiple spoke groups in a region. In this topology, each spoke can be part of only one region and one spoke group.


The following figure shows that Region A has two spoke groups, Spoke Group-1 and Spoke Group-2, and that each spoke group has two spokes. Region B has two spoke groups, Spoke Group-3 and Spoke Group-4, each containing two spokes. If a spoke in one region needs to communicate with a spoke in another region, traffic from one spoke first goes through the local hub and then through the remote hub, which then forwards the traffic to the remote spoke.

In this type of topology, you can configure hubs simply as hubs. You cannot configure them as hub-controller nodes. For more information, see [Hub-Controller Node](#), below.



## Hub-Controller Node

The Versa Operating System™ (VOS™) node personality hub-controller node (HCN) functions as both a hub and a Controller node, serving the spokes that are in the same region. The following figure shows HCNs deployed in an SHHS topology. Spokes establish IKE IPsec tunnels to the local HCNs. Only HCNs establish IKE IPsec tunnels to the top-level Controller nodes.



For large SD-WAN networks deployed by service providers or enterprises, you can segment the network into multiple regions for better scalability. You can deploy two or more HCNs in each region serving as Controller nodes and hubs for the spokes in the region. You interconnect the hubs using top-level Controller nodes. In a service provider environment, HCNs are typically multitenant and are shared by multiple customers, similar to regular Controller nodes. As with normal hubs, you onboard HCNs using the zero-touch provisioning (ZTP) process. You can onboard additional customer tenants by updating the workflow templates and then committing the changes.

In SD-WAN networks in which there is no direct communication between spoke devices and a staging Controller node, you can configure the HCN as a staging Controller node by selected the Staging value in the template workflow. When you configure an HCN as a staging Controller node, remote spokes can be loaded with boot configurations that make them connect to one of the HCNs for ZTP. As with regular staging Controller nodes, URL ZTP is supported through HCNs.

The following screenshot shows a Hub Controller device type that is configured to be a Staging Controller node. You can add subtenants when you create a template workflow or by editing an existing template workflow and redeploying it.

The following screenshot shows a newly created hub–controller.

Note that if the hub–controller is behind a NAT, you must configure a public IP address when you configure a WAN interface in the SD-WAN site settings so that the spokes can communicate with the HCN. For more information, see [Configure SD-WAN Sites](#).

A spoke group can connect either to a regular hub or to a hub–controller, but not to both. To enforce this requirement, you must select either Hub or Hub–Controller when you configure the spoke group. For backward compatibility, the default spoke group type is Hub

When you create a spoke device using the device workflow, IKE IPsec PSK information is set automatically on the corresponding HCN for each device. When you commit the templates to the HCN devices, the PSK information is preserved on the hubs.

## Regional Hub-and-Controller Configuration Overview

To configure a region and hub-and-Controller nodes, you do the following:

- Create a region.

[https://docs.versa-networks.com/Secure\\_SD-WAN/01\\_Configuration\\_from\\_Director/SD-WAN\\_Configuration/Configure\\_SD-...](https://docs.versa-networks.com/Secure_SD-WAN/01_Configuration_from_Director/SD-WAN_Configuration/Configure_SD-...)


Updated: Wed, 23 Oct 2024 08:12:00 GMT


Copyright © 2024, Versa Networks, Inc.

- Deploy a Controller node.
- Associate Controller nodes with an organization.
- Create a template for the hub–Controller node
- Create a device for the hub–Controller node.
- Create a spoke group.
- Create a spoke template.

## Create a Region

1. In Director view, select the Configuration tab in the top menu bar.
2. Select Objects > Regions in the horizontal menu bar.



3. Click the  Add icon. In the Add Region window popup, enter information for the following fields.

Add Region

Name\*

region-51-west

Description

Region ID\*

51

OK

Cancel


Field	Description
Name (Required)	Enter a name for the region.  <i>Value:</i> Text string from 1 through 255 characters long

Field	Description
	<i>Default:</i> None
Description	Enter a text description for the region.
Region ID (Required)	Enter a region identifier. <i>Range:</i> 0 through 100 <i>Default:</i> None

- Click OK.


## Deploy a Controller

- In Director view, select the Workflows tab in the top menu bar.
- Select Infrastructure > Controllers in the left menu bar.



The screenshot shows the Versa Networks Director interface. The top navigation bar includes 'Monitor', 'Configuration', 'Workflows' (highlighted), 'Administration', and 'Analytics'. The left sidebar shows 'Infrastructure' expanded, with 'Controllers' selected. The main content area displays a table of controllers.

Name	Global Controller ID	Status	Last Modified Time	Last Modified By
<input type="checkbox"/> <a href="#">Controller1</a>	1	Deployed	Sat, Sep 29 2018, 05:12	Administrator
<input type="checkbox"/> <a href="#">Controller2</a>	2	Deployed	Sat, Sep 29 2018, 05:12	Administrator
<input type="checkbox"/> <a href="#">Controller3</a>	3	Deployed	Sat, Sep 29 2018, 05:13	Administrator
<input type="checkbox"/> <a href="#">Controller4</a>	4	Deployed	Sat, Sep 29 2018, 05:14	Administrator

- Click the  Add icon. The Deploy Controller popup window displays. For the four tabs on this popup window, provide configuration information as described in the following steps. Mandatory information is indicated with a red asterisk. Click Continue to move to the next tab in sequence and Back to move to the previous tab, or select a tab to move directly to its window.
- Select the General tab, and provide the basic information about the Controller node. Enter information for the following fields.



Deploy Controller - Controller1

General
Location Information
Control Network
WAN Interfaces

Controller

Name \*
Controller1

Provider Organization
Provider

Global Controller ID
1

+ Create Organization

☐ Peer Controller

☐ Sub Organizations

☒ Staging Controller

☒ Post Staging Controller

Customer1-multi-instance

Customer2-single-instance

Resource

☒ Baremetal
☐ Create Virtual Machine

IP Address
10.40.254.2

Analytics Cluster
Analytics

+ Analytics Cluster

Cancel
Continue

Field	Description
Name (Required)	Enter a name for the Controller node.  <i>Value:</i> Text string from 1 through 255 characters long  <i>Default:</i> None
Provider Organization	Select a provider organization.
Global Controller ID	Enter a global Controller identifier. <i>Range:</i> 1 through 31 <i>Default:</i> None
Resource	Select a resource: <ul style="list-style-type: none"> <li>Bare Metal</li> <li>Create Virtual Machine</li> </ul>
IP Address	Enter the management IP address of the Controller.
Analytics Cluster	Select the Analytics cluster.
+ Analytics Cluster	Click to add an Analytics cluster.

5. Select the Location Information tab. Enter location information, and then click Get Coordinates.

6. Select the Control Network tab to configure information about the Controller network. Enter information for the following fields.

Field	Description
Control Network (Group of Fields)	
◦ Network Name	Enter a name for the network.
◦ Interface	Select the network
◦ VLAN ID	Enter the VLAN ID.
◦ IP Address/Prefix	Enter the interface's IP address.
◦ Gateway	Enter the IP address of the gateway associated with the IP address.

Field	Description
<ul style="list-style-type: none"> <li>Routing Protocol</li> </ul>	<p>Select the routing protocol to use:</p> <ul style="list-style-type: none"> <li>None</li> <li>BGP</li> <li>OSPF</li> <li>Static</li> </ul>
Area ID (Required)	Enter the area ID.

7. Select the WAN Interfaces tab to configure information about the WAN interfaces.

Deploy Controller - Controller1

General Location Information Control Network **WAN Interfaces**

WAN Interfaces +WAN Interface

Interface	VLAN ID	Network Name	IPv4				IPv6				Public IP Address		
			Address	Gateway	DHCP	FQDN	Address	Gateway	DHCP	FQDN			
<input type="checkbox"/> vni-0/3	0	--Select--			<input type="checkbox"/>								
<input checked="" type="checkbox"/> vni-0/0	0	Internet1	1.1.1.2/30	1.1.1.1	<input type="checkbox"/>		2001::1:1:1:2/	2001::1:1:1:1	<input type="checkbox"/>				
<input checked="" type="checkbox"/> vni-0/1	0	Internet2	2.2.1.2/30	2.2.1.1	<input type="checkbox"/>		2001::2:2:1:2/	2001::2:2:1:1	<input type="checkbox"/>				
<input checked="" type="checkbox"/> vni-0/2	0	Mpls	3.3.1.2/30	3.3.1.1	<input type="checkbox"/>		2001::3:3:1:2/	2001::3:3:1:1	<input type="checkbox"/>				

Back Cancel

8. Click Deploy.

## Associate Controllers with an Organization

1. In Director view, select the Workflows tab in the top menu bar.
2. Select Infrastructure > Organizations in the left menu bar.

VERSA NETWORKS

Monitor Configuration **Workflows** Administration Analytics

Administrator

Commit Template

Infrastructure


- Controllers
- Organizations**
- Template
- Devices

Name	Global Organization ID	Status	Last Modified Time	Last Modified By
<input type="checkbox"/> Customer1-multi-instance	2	Deployed	Sat, Sep 29 2018, 03:24	Administrator
<input type="checkbox"/> Customer2-single-instance	3	Deployed	Sat, Sep 29 2018, 03:23	Administrator
<input type="checkbox"/> Tenant2	5	Deployed	Sat, May 11 2019, 11:06	Administrator
<input type="checkbox"/> Tenant3	6	Deployed	Sat, May 11 2019, 11:07	Administrator

[https://docs.versa-networks.com/Secure\\_SD-WAN/01\\_Configuration\\_from\\_Director/SD-WAN\\_Configuration/Configure\\_SD-...](https://docs.versa-networks.com/Secure_SD-WAN/01_Configuration_from_Director/SD-WAN_Configuration/Configure_SD-...)

Updated: Wed, 23 Oct 2024 08:12:00 GMT

Copyright © 2024, Versa Networks, Inc.

3. Click the  Add icon. In the Create Organization popup window, enter information for the following fields.

Create Organization - Customer1-multi-instance

Organization

Name\*

Customer1-multi-instance

Global Organization ID

2

Parent

Provider

IKE Authentication

PSK

PKI

Staging CA Agent

Post Staging CA Agent

SCP

Shared Control Plane

CPE Deployment Type

SDWAN

Controllers

CMS Connectors

Analytics Cluster

Routing Instances

Supported User Roles

Controllers

Available

Add All

Search

Selected

Remove All

Search

Controller1

×

Controller2

×

Controller3

×

Controller4

×

Cancel

Redeploy


Field	Description
Name (Required)	<div>Enter a name for the organization.</div> <div>Value: Text string from 1 through 255 characters long</div> <div>Default: None</div>


Field	Description
Global Organization ID	Enter a global organization identifier.
Parent	Select the parent organization.

4. Select the Controllers tab.
5. In the Available pane, click the Controllers to associate them with the organization. The Controllers move to the Selected pane.
6. Click Redeploy.






## Create a Template for a Hub–Controller Node


1. In Director view, select the Workflows tab in the top menu bar.
2. Select Template > Templates in the left navigation bar.



3. Click the  Add icon. The Create Template popup window displays. For the eight tabs on this popup window, provide configuration information, as described in the following steps. Mandatory information is indicated with a red asterisk. Click Continue to move to the next tab in sequence and Back to move to the previous tab, or select a tab to move directly to its window.
4. Select the Basic tab to configure basic interface properties. Enter information for the following fields.

Field	Description
Name (Required)	<p>Enter a name for the template.</p> <p><b>Value:</b> Text string from 1 through 255 characters long</p> <p><b>Default:</b> None</p>
Type (Required)	<p>Select the template type:</p> <ul style="list-style-type: none"> <li>SD-WAN Post-Staging</li> <li>SD-WAN Staging</li> </ul>
Organization (Required)	<p>Select the organization to which this template applies.</p>
Device Type	<p>Select the device type:</p> <ul style="list-style-type: none"> <li>Full Mesh—Set the device in a full-mesh topology. This is the default setting.</li> <li>Hub—Have the device be a hub in a hub-and-spoke topology.</li> <li>Hub Controller—Configure the device to act as a hub and a Controller for the (see the description of the Region field below).</li> <li>Spoke—Have the device be a spoke in a hub-and-spoke topology. If you select this option, the Spoke Group field is enabled. Enter the name of the spoke group.</li> <li>Staging—Configure the device as a staging Controller when there is no direct connection to the network devices and a staging Controller. This field is only visible when you select Hub Controller.</li> </ul>
Region	<p>For a device type of hub or hub controller, select the region.</p>

Field	Description
Redundant Pair	<p>Click Enable to create a redundant template, which is required when you are using a redundant solution.</p> <ul style="list-style-type: none"> <li>Cloud CPE—Click to enable a cloud-based CPE solution for redundancy. You must have previously selected VRRP.</li> <li>Template Name—Enter the name of the template to use for redundancy.</li> <li>VRRP—Click to enable VRRP for the redundant pair.</li> </ul>
Suborganizations	<p>Click the  Add icon to associate one or more suborganizations with the template in the drop-down list.</p> <p>To remove a suborganization from the list, select the suborganization and click the .</p> <p>When you select the device type as Spoke, the Spoke Group field displays and you can select a suborganization.</p>
Controllers (Required)	<p>Click the  Add icon to associate one or more Controller nodes with the template in the drop-down list.</p> <p>To remove a Controller node from the list, select the Controller node and click the .</p>
Subscription (Group of Fields)	
◦ Solution Tier (Required)	Select the solution tier that corresponds to the license that the device is using.
◦ Service Bandwidth	Select the bandwidth to use for solution tier that corresponds to the license that the device is using. Select multiple bandwidths.
◦ Aggregate Bandwidth	If you select multiple service bandwidths, this field displays the total aggregate bandwidth.
◦ Solution Add-On Tier	Select a solution tier for the post-staging template.
Custom Parameters	<p>Enter custom subscription-related parameters:</p> <ul style="list-style-type: none"> <li>Name—Name used to identify the parameter.</li> <li>Value—Value of the parameter.</li> </ul> <p>Click the  Add icon to add the custom parameter to the template.</p>

Field	Description
Primary	<p>Select if this is the primary solution tier. The license pricing depends on the selected bandwidth.</p> <p>Unselect if you are applying the template to the standby device in a high availability configuration.</p>
Analytics Enables	<p>Select to have the device generate logs on and send logs to Versa Analytics.</p> <p>Unselect if your deployment does not use Versa Analytics.</p>
Analytics Cluster	Select the Analytics cluster to use for the device.
+ Analytics Cluster	Click to create an Analytics cluster. In the Create Analytics Cluster popup window:
◦ Cluster Name (Required)	Enter a name for the cluster.
◦ Northbound IP	<p>Enter a name to identify the northbound IP address, enter the IP address for the northbound interface.</p> <p> Add icon to add the IP address.</p>
◦ Connector Port	Select the port number to use for the northbound connection.
◦ Collector (Required)	<p>Enter information about the Analytics cluster collector:</p> <ul style="list-style-type: none"> <li>◦ Southbound IP—(Required) Enter the IP address for the southbound interface. Enter the IP address.</li> <li>◦ Collector Port—Enter the port number to use on the collector.</li> </ul> <p>Then, click OK.</p>
Preferred Software Version	Select the preferred version of the software to deploy on the VOS device. Note that the Director node upgrades a branch device to the minimum software version, which is compatible with up to the two previous software versions.

5. Select the Interfaces tab to specify the WAN and LAN interfaces. Enter information for the following fields.



Edit Template - HCN1-West

Basic
Interfaces
Routing
Tunnels
Inbound NAT
Services
Management Servers

Device Port Configuration

Number of Ports
6

0
1
2
3
4
5

Mgmt
WAN
WAN
WAN
LAN

4G
LTE
WiFi

WAN Interfaces

Port #	Interface	VLAN ID	Network Name	Priority	IPv4		IPv6		Allow SSH To CPE	Link Monitor		Sub Interfaces
					Static	DHCP	Static	DHCP		Nexthop	Remote IP	
0	vni-0/0		Internet1		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	+
1	vni-0/1		Internet2		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	+
2	vni-0/2		Mpls		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	+

LAN Interfaces

Port #	Interface	VLAN ID	Network Name	Organization	Zones	Routing Instance	IPv4		IPv6		Sub Interfaces
							Static	DHCP	Static	DHCP	
4	vni-0/4	201	T2-LAN1	Tenant2	--Select--	Tenant2-LAN-1-VR	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	+
		202	T2-LAN2	Tenant2	--Select--	Tenant2-LAN-2-VR	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
		301	T3-LAN1	Tenant3	--Select--	Tenant3-LAN-1-VR	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
		302	T3-LAN2	Tenant3	--Select--	Tenant3-LAN-2-VR	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

Back
Cancel
Continue
Recreate



Field	Description
Device Port Configuration (Group of Fields)	Configure the ports on the VOS device.
<ul style="list-style-type: none"> <li>Number of Ports</li> </ul>	Select the number of ports on the device.
<ul style="list-style-type: none"> <li>Port icons</li> </ul>	Right click on the port icon, and from the popup window select the type of interface. <ul style="list-style-type: none"> <li>LAN (green)</li> <li>Management (yellow)—Port 0 is always the management interface.</li> <li>PPPoE (light blue)</li> <li>WAN (dark blue)</li> <li>WAN and LAN (dark blue and green)</li> <li>Unassigned (gray)</li> </ul>
<ul style="list-style-type: none"> <li>LTE icon</li> </ul>	Click the blue LTE port icon to configure LTE on a WAN interface. You can create up to eight interfaces. The VOS device automatically assigns a port number from 100 through 199.
<ul style="list-style-type: none"> <li>WiFi icon</li> </ul>	Click the green WiFi port to configure Wi-Fi for the LAN. You can create up to eight interfaces. The VOS device automatically assigns a port number from 200 through 299. These interfaces support only DHCPv4.
WAN Interfaces (Group of Fields)	This section populates when you add WAN interfaces, with one row for each port.
<ul style="list-style-type: none"> <li>Port Number</li> </ul>	Displays the port numbers selected for WAN ports, including PPPoE and LTE interfaces.


[https://docs.versa-networks.com/Secure\\_SD-WAN/01\\_Configuration\\_from\\_Director/SD-WAN\\_Configuration/Configure\\_\\_SD-...](https://docs.versa-networks.com/Secure_SD-WAN/01_Configuration_from_Director/SD-WAN_Configuration/Configure__SD-...)

Updated: Wed, 23 Oct 2024 08:12:00 GMT

Copyright © 2024, Versa Networks, Inc.

17

Field	Description
	<p>If you selected Redundancy in the General tab, port mapping of the redundant CPE interface on the Primary device, LAN interfaces are automatically selected on the Primary device.</p> <p>If the active, redundant CPEs are not connected to the exact same WAN network, the Primary device.</p>
◦ Interface	Displays the VNI interface and subinterface numbers selected for the port.
◦ VLAN ID	Enter the VLAN ID for the subinterfaces. To parameterize the VLAN ID, click the
◦ Network Name	Select the network name for WAN interface. To create a new network name, click
◦ Priority	<p>Link priority for WAN traffic. A default forwarding profile is automatically created with priority. If you do not assign a priority, the WAN interface is added to the default forwarding profile.</p> <p>To parameterize the priority, click the  Parameterize icon.</p>
◦ IPv4	<p>Use IPv4 addressing on the WAN interface:</p> <ul style="list-style-type: none"> <li>◦ Static—Use static IP address. When you select Static, a bind-data variable for the IP address is automatically generated in the template.</li> <li>◦ DHCP—Use DHCP to obtain an IP address.</li> </ul>
◦ IPv6	<p>Use IPv6 addressing on the WAN interface:</p> <ul style="list-style-type: none"> <li>◦ Static—Use static IP address. When you select Static, a bind-data variable for the IP address is automatically generated in the template.</li> <li>◦ DHCP—Use DHCP to obtain an IP address.</li> </ul>
◦ Allow SSH to CPE	Click to allow an SSH session to the CPE on the underlay IP address of WAN interface.
◦ Link Monitor	Select to monitor the reachability of the next hop or remote IP address on the WAN interface. If the link becomes unreachable, DIA traffic is directed to another WAN interface if possible.
◦ Subinterfaces	<p>Click the  Add button to add a subinterface on the WAN port. Another row is added for the subinterface. For the subinterface, configure all the fields described above.</p>

Field	Description
LAN Interfaces (Group of Fields)	This section populates when you add LAN interfaces or WiFi ports, with one row
◦ Port Number	Displays the port numbers selected for LAN ports and WiFi interfaces.
◦ Interface	Displays the VNI interface and subinterface numbers selected for the port.
◦ VLAN ID	Enter the VLAN ID for the subinterfaces. To parameterize the VLAN ID, click the
◦ Network Name	Select the network name for LAN interface.
◦ Organization	Select the organization to which the interface belongs.
◦ Zones	Select the zone to which LAN interface belongs. If you do not select a zone, the L associated with a zone based on the LAN network name.
◦ Routing Instance	Select the organization's routing instance with which the LAN interface is associa
◦ IPv4	Use IPv4 addressing on the WAN interface: <ul style="list-style-type: none"> <li>◦ Static—Use static IP address. When you select Static, a bind-data variable f automatically generated in the template.</li> <li>◦ DHCP—Use DHCP to obtain an IP address.</li> </ul>
◦ IPv6	Use IPv6 addressing on the WAN interface: <ul style="list-style-type: none"> <li>◦ Static—Use static IP address. When you select Static, a bind-data variable f automatically generated in the template.</li> <li>◦ DHCP—Use DHCP to obtain an IP address.</li> </ul>
◦ Subinterfaces	Click the  Add button to add a subinterface on the WAN port. Another row is a For the subinterface, configure all the fields described above.

6. Click Recreate.


## Create a Device Group for the Hub–Controller Node

1. In Director view, select the Configuration tab in the top menu bar.
2. Select Devices > Devices Group in the left menu bar.

[https://docs.versa-networks.com/Secure\\_SD-WAN/01\\_Configuration\\_from\\_Director/SD-WAN\\_Configuration/Configure\\_\\_SD-...](https://docs.versa-networks.com/Secure_SD-WAN/01_Configuration_from_Director/SD-WAN_Configuration/Configure__SD-...)

Updated: Wed, 23 Oct 2024 08:12:00 GMT

Copyright © 2024, Versa Networks, Inc.



- Click the  Add icon. In the Add Device Group popup window, enter information for the following fields.

**Add Device Group**

Name\*

Description

Tags

Organization\*  ☐ Enable Two Factor Auth ☐ CA In Data Center

Staging Template  Post Staging Template  General

**Contact Information**

Email  Phone

Post Staging Template Association(4) Devices(0) URL Based ZTP

Tenant	Category	Template
Provider	Main	HCN1-West
Provider	DataStore	Provider-DataStore
Tenant2	DataStore	Tenant2-DataStore
Tenant3	DataStore	Tenant3-DataStore

OK Cancel

Field	Description
Name (Required)	<p>Enter a name for the organization.</p> <p><i>Value:</i> Text string from 1 through 255 characters long</p>

Field	Description
	<i>Default:</i> None
Organization (Required)	Select an organization.
Post-Staging Template	Select a template.


4. Select the URL-Based ZTP tab. Enter information for the following fields.

Field	Description
URL-Based ZTP	Select the type of staging: <ul style="list-style-type: none"> <li>◦ Prestaging</li> <li>◦ Staging</li> </ul>
Controller (Required)	Select a Controller node
VPN Profile (Required)	Select a VPN profile.

5. Click OK.

# Create a Device for the Hub–Controller Node

- 1. In Director view, select the Workflows tab in the top menu bar.
- 2. Select Devices > Devices Group in the left menu bar.



- 3. Click the Add icon. The Add Device window popup displays. For the three tabs on this popup window, provide configuration information, as described in the following steps. Mandatory information is indicated with a red asterisk. Click Continue to move to the next tab in sequence and Back to move to the previous tab, or select a tab to move directly to its window.
- 4. Select the Basic tab to configure basic information about the device. Enter information for the following fields.

Add Device - HCN101

BasicLocation InformationURL Based ZTPBind Data

Name\*HCN101

Global Device ID\*101

Organization\*Provider

Deployment TypeCPE-Baremetal Device

Serial Number47e29ecf-5111-4b6d-8c68-a84a0a3bd946

Device Groups\*HCN1-DG-W

Generate Serial Number

Admin Contact Information

Subscription

EmailPhone Number

Service BandwidthAggregate Bandwidth

CancelSaveContinueRedeploy

Field	Description
Name (Required)	Enter a name for the device.

Field	Description
Organization	Select an organization.
Deployment	Select the deployment type: <ul style="list-style-type: none"> <li>◦ CPE-Bare Metal Device</li> <li>◦ CPE-Public Cloud</li> </ul>
Serial Number	Enter the device's serial number.
Device Groups	Select the device group in which to place the device.

5. Select the Location Information tab. Select the country and click Get Coordinates.

The screenshot shows the 'Add Device - HCN101' dialog box with the 'Location Information' tab selected. The 'Location' section contains the following fields and values:

Field	Value
Address 1	
Address 2	
City	las vegas
State	LV
Country	USA
Zip	
Latitude	36.169941
Longitude	-115.13983

The 'Country' field is highlighted with a red box, and the 'Get Coordinates' button is visible below it. The dialog box also includes a 'Back' button and 'Cancel', 'Save', 'Continue', and 'Redeploy' buttons at the bottom.

6. Select the URL-Based ZTP tab to specify authentication and network information.

Add Device - HCN101

Basic Location Information URL Based ZTP Bind Data

Authentication Info

PSK PKI

Auth ID HCN101@Provider.com Auth Key 1234

Network Info

VLAN MTU DNS Server

IPv4 IPv6 DHCP v4 DHCP v6 PPPoE

Address\* 70.70.25.2/24 Gateway\* 70.70.25.1

Back Cancel Save Continue Redeploy

7. Select the Bind Data tab to enter the post-staging template details.

Add Device - HCN101

Basic Location Information URL Based ZTP Bind Data

User Input Auto-Generated

Post Staging Template - HCN1-West

Serial	Device Name	Internet1_IPv4_staticaddress	Internet2_IPv4_staticaddress	Mpls_IPv4_staticaddress
47e29ecf-5111-4b6d-8c...	HCN101	70.70.25.2/24	80.80.25.2/24	10.100.25.2/24

Service Template Variable Template : HCN1-West Device Group : HCN1-DG-W

Service Templates : Provider-DataStore

User Input Auto-Generated Clone Clear

Serial	Device Name
47e29ecf-5111-4b6d-8c68-a84a0a3bd946	HCN101

Validate Template

Back Cancel Save Redeploy

8. Click Redeploy.

## Create a Spoke Group

1. In Director view, select the Workflows tab in the top menu bar.


[https://docs.versa-networks.com/Secure\\_SD-WAN/01\\_Configuration\\_from\\_Director/SD-WAN\\_Configuration/Configure\\_SD-...](https://docs.versa-networks.com/Secure_SD-WAN/01_Configuration_from_Director/SD-WAN_Configuration/Configure_SD-...)


Updated: Wed, 23 Oct 2024 08:12:00 GMT


Copyright © 2024, Versa Networks, Inc.



2. Select Template > Spoke Groups in the left menu bar.




3. Click the  Add icon to create a spoke group. Enter information for the following fields.



Field	Description
Name (Required)	Enter a name for the spoke group.
Organization (Required)	Select an organization.
Region	Select the region where the spoke group is deployed.
Hub, Hub Controller	Click Hub Controller to have the spoke group connect to a hub–Controller node.

## Create a Spoke Template

1. In Director view, select the Workflows tab in the top menu bar.
2. Select Template > Templates in the left menu bar.
3. Click the  Add icon to create a spoke template. The Create Template popup window displays.

**Create Template**

Basic | Interfaces | Routing | Tunnels | Inbound NAT | Services | Management Servers

Name\*  Type\*  Organization\*

Device Type:    
☐ Full Mesh ☐ Hub ☐ Hub Controller ☒ Spoke   
 Spoke Group:

Redundant Pair: ☐ Enable ☐ VRRP ☐ Cloud CPE   
 Template Name:

Sub Organizations:  Spoke Group:    
 No Records to Display

Controllers:    
 No Records to Display

Analytics Cluster:    
 + Analytics Cluster Preferred Software Version:

Subscription:   
 Solution Tier\*:    
 Service Bandwidth:    
 Aggregate Bandwidth:

Solution Addon Tier:    
 No Records to Display

Custom Parameters:   

Name	Value
<input type="text"/>	<input type="text"/>

 No Records to Display

☒ Primary   
☒ Analytics Enabled

Cancel Save Continue

4. In the Basic tab, select Spoke.
5. In the Spoke Group field, select a spoke group.
6. Click Recreate.
7. Create a device spoke group and a spoke device, as described above.
8. Click Save.

## Supported Software Information

Releases 20.2 and later support all content described in this article, except:

- Release 20.2.1 adds support for creating multiple spoke groups in a region.

## Additional Information

[Configure SD-WAN Hubs](#)

[Configure SD-WAN Sites](#)

[Create an SD-WAN Spoke Group](#)