
Install a CSG150 Series Appliance

This article provides instructions about how to unpack and install a CSG150 series appliance.

Unpack a CSG150 Series Appliance

The CSG150 series appliance is packed in a plastic box, and it is shipped in a cardboard carton, secured with foam packing material. The carton also contains an accessory box. It is recommended that you unpack the appliance only when you are ready to install it.

To unpack a CSG150 series appliance:

1. Open the top flaps of the cardboard carton.
2. Remove from the box the foam packing material holding the appliance and the accessories in place.
3. Remove the accessory box and the appliance from the foam packing material.
4. Remove the accessories from the accessories box.
5. Verify the components against the packing list that is included in the box.

Note: It is recommended that you save the shipping carton and packing material when unpacking the appliance, in case you need to later move the appliance or return it. See [How To Return Hardware](#).

Packing List for a CSG150 Series Appliance

The cardboard carton in which a CSG150 series appliance is shipped contains a packing list. Check the packing list against the parts that you receive in the shipping carton.

Packing List for the CSG150 Appliance

Table 1 lists the parts shipped with a CSG150 appliance.

Table 1: Parts Shipped with a CSG150 Appliance

Components	Quantity
CSG150 appliance chassis	1
AC power adapter	1
Standard 3-prong C13 power cable, minimum 2 Amps (US only)	1